
FPGAFlow Documentation

Electronic System Design Group, Technology

Aug 16, 2020

Contents

1 Adding Python Modules	3
1.1 License	3
1.1.1 Index:	3
1.1.1.1 Readme	3
1.1.1.2 Changelog	4
1.1.1.3 Modules	8
1.1.1.4 Arguments	39
1.1.1.5 Configuration	42
1.1.1.6 EXCLUDE Files	58
1.1.1.7 Installation	58
1.1.1.8 Known Issues	61
1.1.1.9 Directory Layouts	61
1.1.1.10 Settings	63
1.1.1.11 Utils	75
1.1.1.12 Vendor IP	76
1.1.1.13 VUnit Integration	79
1.1.2 Indices and Tables:	79
Python Module Index	81
Index	83

Electronic System Design Group

FPGAF_{low} is a python script to handle a complete FPGA design flow where the design files, libraries and supplementary tools are stored in a source code repository.

See [*Installation*](#) for installation notes.

CHAPTER 1

Adding Python Modules

When adding new python modules to: \$REPO_ROOT/tools/fpgaflow/scripts/python/fpgaflow/Pipfile the pip requirements.txt must also be updated to ensure <https://fpgaflow.readthedocs.io/en/latest/index.html> automatic build can operate correctly. This can be achieved by running:

```
cd $REPO_ROOT/tools/fpgaflow/scripts/python/fpgaflow/  
pipenv lock -r
```

and copying the output to: \$REPO_ROOT/tools/fpgaflow/scripts/python/fpgaflow/requirements.txt

1.1 License

BSD © 2018-2019 Science and Technology Facilities Council & contributors

1.1.1 Index:

Electronic System Design Group

1.1.1.1 Readme

FPGAFlow is a python script to handle a complete FPGA design flow where the design files, libraries and supplementary tools are stored in a source code repository.

See [Installation](#) for installation notes.

Adding Python Modules

When adding new python modules to: \$REPO_ROOT/tools/fpgaflow/scripts/python/fpgaflow/ Pipfile the pip requirements.txt must also be updated to ensure <https://fpgaflow.readthedocs.io/en/latest/index.html> automatic build can operate correctly. This can be achieved by running:

```
cd $REPO_ROOT/tools/fpgaflow/scripts/python/fpgaflow/
pipenv lock -r
```

and copying the output to: \$REPO_ROOT/tools/fpgaflow/scripts/python/fpgaflow/ requirements.txt

License

BSD © 2018-2019 Science and Technology Facilities Council & contributors

Electronic System Design Group

1.1.1.2 Changelog

- : Workaround to prevent Sphinx from processing non-html files when parsing documentation generated using Doxygen.
- : Added argument to allow skipping of XML2VHDL generation. --skip_xml2vhdl
- #4: Added git support for cloning dependencies from git repositories. Renamed \$REPO_USERNAME \$SVN_USERNAME to allow the script to differentiate between git and svn repositories. This requires an update to ~/.cshrc before FPGAFlow will execute successfully.
- : Fixed path locations for documentation templates when executing FPGAFlow from a virtual environment.
- : Fixed running project without specifying a board.
- #3: Fixed issue where --clean precompiled_sim failed to clean the pre-compiled simulation libraries and --clean fpga failed to clean (and backup) the project build location.
- : Overrides the vunit_args: num_threads: value in the corresponding settings YAML file if --open_project sim is used. This is to prevent multiple Modelsim GUI instances from spawning when using this command line argument.
- : Tag replacement runs when setting \$LD_LIBRARY_PATH from configuration YAML file.
- #1: Add Bamboo support to FPGAFlow.
- #2: Fixed issue where build in \$REPO_ROOT or \${bamboo.REPO_ROOT} prevents any source code from being added by FPGAFlow.
- : Fixed file paths to referenced files in packaged version.
- : Moved xml2vhdl usage from sys.path addition to using packaged version. This is now included in the Pipfile, assuming xml2vhdl is checked out under \$REPO_ROOT/tools/xml2vhdl
- : Added support for searching for and adding HDL test-benches to corresponding libraries within the VUnit object.

- : `projectflow.ProjectFlow` Checks if test-bench simulation files exist matching the `self.top_level_tb_entity[0]` value from `Settings`.
- : `fpgavendor_iface.FpgaProject.create_quartus_project` adds top-level HDL test-bench to quartus project if it is successfully located on the file-system.
- : Added `funcs.vunit_tb_cfg_encode` to handle global encoding of VUnit test-bench configuration when running VUnit.
- : Updated `arguments` and `vuint_iface.VUnitProject` to handle additional arguments required by `vunit_hdl>=0.3.9` which prevented VUnit from running test-cases.
- : Passing `--open_gui sim` and `--clean all --clean sim` arguments to VUnit.
- : Added generation of timestamp parameter for automatically inserting a Unix timestamp into the HDL top-level via a generic entry. This can be enabled/disabled from the board settings file using the: `board_timestamp_enabled: <True|False>` option.
- : Added generation of `board_id` parameter for automatically inserting a `board_id` into the HDL top-level via a generic entry. This can be configured from the board settings file using the: `board_id: "00000000"` option. Where the ID is a hex presentation of a 32 bit unsigned number.
- : `fpgavendor_iface.FpgaProject.create_quartus_project` now replaces all absolute paths with `$env(REPO_ROOT)`, this means that the resulting `project_gen.tcl` has no references to the users working location and can be committed in the revision control system. When copying `.qsf` files line-by-line, blanks and commented-out lines are ignored, if the user wants comments to be copied the script will add any comment starting with more than one # comment character.
- : Added Argument parsing for `--open_gui` and `--clean`, see `Arguments`. These arguments deprecate options in the `Settings`. Converted `--checkout_disabled` to `--checkout_enabled` as the majority of user use cases are working on checked out locations.
- : `qsys-generate` now generates both for synthesis and simulation. When parsing the generated Modelsim generation script, the top-level simulation file is now added to the VUnit object to a HDL library matching the top-level HDL file for the IP. This matches the configuration as described in the corresponding generated `.qip` file.
- : Fixed issue hen parsing enabled `vendor_ip` in project where common wrapper file location was being to aggressive on determining wrapper file search path. Search locations are determined by: 1. wrapper file directory matches the IP name and 2. wrapper file directory matches the IP wrapper name (with `_wrapper` suffix stripped).
- : Fixed issue where `docflow.ProjectDoc.generate_automodule` added duplicate entries for modules found in the `/build` and `/dist` paths.
- : Fixed duplication of project name when building projects if board name and project name match.
- : Modified build path creation. If the build path is in boards the script will no longer duplicate `vendor` and `tool_version` in the constructed build path, as they already exist for the board being targeted.
- : Added `MANIFEST.in` to include all files required by FPGAFLOW to PyPi.
- : Restructured layout of FPGAFLOW to allow for use of `setuptools`. Added `setup` which can be executed using: `python setup.py sdist bdist_wheel` from: `$REPO_ROOT/tools/fpgaflow/scripts/python/fpgaflow-esdg`
- : Fixed type in `vunit_iface` which caused default language to always be used when compiling standard libraries for Modelsim by invoking quartus.
- : Fixed issue with `--checkout_disabled` and `--dev` argument usage evaluating against the str "False" rather than the boolean False which prevented SVN checkouts.
- : Fixed issue where duplicate `vendor_ip` wrapper files were added to VUnit.

- : Fixed issue where missing vendor_ip locations caused the script to crash. Now they raise a critical warning.
- : Fixed issue where double slashes: // in \$REPO_ROOT causes VUnit to fail to get sourcefile objects.
- : Added `fpgavendor_iface` module
- : Added provision to compile standard libraries for Modelsim by invoking vivado.
- : Added glbl support for vivado based simulations.
- : Added provision to compile standard libraries for Modelsim by invoking quartus. Converted `fpgavendor_iface.run_quartus_sh` and `fpgavendor_iface.run_vivado` from positional arguments to keyword arguments.
- : Added `projectflow.ProjectFlow.generate_project_name`.
- : Added support for boards. Boards are now handled in the same way as project dependencies.
- : Added support for mapping top-level directory names to other values. `projectmanager.ProjectDependency.top_dir_lookup`. Added documentation: *Directory Layouts*
- : Added `vendor_ip_handler` to process vendor_ip design files.
- : Added `board_handler` to process board design files, which overwrites project settings to target specific hardware.
- : Updated `vendor_ip` support. Changed method to add IP files and Wrapper Files.
- : Removed `vendor_ip_handler`. This is now handled by `projectflow` and `projectmanager`
- : Removed `board_handler`. This is now handled by `projectflow` and `projectmanager`
- : Added `fpgavendor_iface.FpgaProject.create_quartus_project` which creates a line-by-line tcl script to generate a quartus project file. HDL source files are determined from VUnit object which has all found hdl files in the project. If a top-level board file fails to include the project's top-level file the script will add the top-level project file and dependencies, but until a a project to board mechanism is developed the project to board wrapper will need to be manually added.
- : Added constraint file processing to `projectflow.ProjectFlow`.
- : Generated `project_gen.tcl` is now generated in the root project build path. Generates quartus project, and uses `rebuild_project: <True|False>` settings value to determine if existing projects should be backed up.
- : Added *Known Issues* to document problems and solutions to problems executing the script.
- : Added `fpgavendor_iface.run_ip_setup_simulation` to process quartus project file for extracting vendor_ip simulations files.
- : Added `fpgavendor_iface.run_ip_generate` to generate quartus vendor_ip.
- : Added `vunit_iface.compile_project_ip` to compile vendor_ip simulation files from enabled vendor_ip.
- : Added --open_project argument, which opens generated project in GUI.
- : Parses vendor_ip simulation compile order, derived from quartus project, and adds libraries and HDL to VUnit object.
- : Fixed issue where relative paths in `docflow` were incorrectly relative to the calling location when generating documentation for other modules.
- : Fixed bug where vendor specific HDL source code was not filtered when adding to VUnit.
- : Added documentation: header: support for modifying the common header used in generated sphinx documentation

- : Expanded automodule exclude term to include `template` instead of `templates`.
- : Added XML2VHDL dependency checking in `projectflow` to ensure that required VHDL libraries are included before proceeding.
- : Added `required_vhdl_libs` option for XML2VHDL VHDL library checking in settings file.
- : Added `projectflow.Xml2Vhdl` to create object for executing `xml2vhdl` script.
- : Added complete set of attributes to replicate arguments to pass to `xml2vhdl` script.
- : Moves into `xml2vhdl` script directory to execute `xml2vhdl`, returns to `projectflow` working directory when complete.
- : Added support for adding *other* FPGA vendors to `exclude_terms` based on *Configuration* file. See [*supported_vendors*](#):
- : Added support for getting `exclude_terms` from *Configuration* file. See [*exclude_keywords*](#):
- : Added `projectflow.ProjectFlow.search_paths_for_files` to recursively search paths taking into account `exclude_terms` and [*EXCLUDE Files*](#)
- : Added `vunit-hdl` for managing and processing HDL designs and simulations.
- : Added `projectflow.ProjectFlow.get_top_level_files` to find top-level HDL files in list of HDL files. If none are defined in [*top_level*](#): the script will exit.
- : Added `arguments.Arguments._vunit_args` which adds VUnit Argument passing from *Settings* instead of command line. Added `args` as attribute to [*environmentsetup.ProjectEnvironment*](#) for use in `projectflow`.
- : Moved `projectflow.Xml2Vhdl` to `xml2vhdl_iface` to tidy up source code.
- : Moved `projectflow.VUnitProject` to `vunit_iface` to tidy up source code.
- : Added documentation for `vunit_args`: to *Settings*.
- : Added `no_color` argument support for VUnit
- : Added `sim_init_script` VUnit support for running GUI mode. Added `--headless` argument processing to override GUI options.
- : Fixed Release number in Documentation
- : Now using `action="store_true"` for `arguments` which will set optional arguments to True if present, False otherwise.
- : Added support for bitbucket username retrieved from system environment variable.
- : Uses `urlparse` to process URL construction for remote repository paths.
- : `projectmanager` now processes both git and subversion repository locations.
- : Renamed `helper helpers` to prevent namespace conflicts when importing `xml2vhdl`. This is a temporary workaround.
- : Added numpy to python virtual environment.
- : Removed obsolete `errorhandling.py` helper module.
- : Added docstrings for helper modules.
- : Grouped helper modules to tidy up documentation.
- : Updated docstring documentation for `projectmanager`
- : Added description of `repository_config`: to the *Settings* document.

- : Updated docstring documentation for *environmentsetup*
- : Added *simulation*: description to *Configuration* documentation page.
- : Added in depth descriptions for *Settings* documentation page.
- : Added *fpga*: descriptions in *Configuration* documentation.
- : Added LICENCE to each python module.
- : Alphabetical ordering of index and modules, based on filename not title.
- : Added *releases* support with this changelog file.
- : Updating documentation for *docflow*
- : Fixed external links in documentation, fixed readthedocs badge usage.
- : Added License link in README.
- : Completed docstring documentation for sphinx based functions in *docflow*
- : Completed docstring documentation for doxygen based functions in *docflow*
- : Started to update docstring documentation for *version* and *arguments*

Electronic System Design Group

1.1.1.3 Modules

`helpers/arguments.py`

BSD © 2018-2019 Science and Technology Facilities Council & contributors

`arguments.py` is a helpers module provided to define and configure the argument passing and parsing for the main modules.

class arguments.Arguments

Creates arguments for passing files and configuration data to the script.

A Class which configures and retrieves Arguments for use by a python script. Dictionaries retrieved from YAML files are added as attributes to this class with no sub-processing. Information including the filename of each YAML file parsed is also added as an attribute.

See *Arguments*

config

dict – the parsed dictionary of the `config.yml` passed using to script `--config`

settings

dict – the parsed dictionary of the `settings.yml` passed to script using `--settings`

checkout_enabled

bool – set True using optional `--checkout_enabled`, otherwise False

dev_flag

bool – set True using optional `--dev`, otherwise False

open_gui

str – Valid values: 'fpga', 'sim'. Using optional `--open_gui`, otherwise None

clean

list of str – Valid values: 'all', 'fpga', 'ip', 'precompiled_sim', 'sim'. Using optiona
clean, otherwise: None

helpers/customlogging.py

BSD © 2018-2019 Science and Technology Facilities Council & contributors

customlogging.py is a helpers module provided to define and configure consistent logging. The logging config-
uration is handled via `../logging.yml` YAML file and uses `colorlog` for console output. A rolling system is
used for outputting to files.

class customlogging.LogLevelsConsts

Logger level equivalent strings as constants, used to pass log level to helpers functions.

DEBUG

str – String matching DEBUG logger level.

INFO

str – String matching INFO logger level.

WARNING

str – String matching WARNING logger level.

CRITICAL

str – String matching CRITICAL logger level.

ERROR

str – String matching ERROR logger level.

customlogging.config_logger (name, class_name=None)

Allows a logger to be set up and/or configured in all modules/module classes

Parameters

- **name** (*str*) – Name of the logger.
- **class_name** (*str, optional*) – Name of the class to which the logger is associated.
Default value: None

Returns A configured logger object.

Return type logging (obj)

customlogging.constant (f)

setters and getters for constants used throughout

Prevents setting of existing objects. Raises a TypeError.

Returns property

Raises TypeError – On setter.

customlogging.errorexit (logr)

Inserts a exit on error message in the logger output and performs a `sys.exit (-1)`

Parameters **logr** (*obj*) – A logger object to pass the exit on error message to.

Returns None

customlogging.mand_missing (obj, field)

Inserts a mandatory field missing error message in the logger output and calls `errorexit ()`

Parameters

- **logr** (*obj*) – A logger object to pass the error message to.
- **field** (*str*) – field to report in the error message.

Returns None

customlogging.**path_missing** (*obj, name, path*)

Inserts a path missing error message in the logger output and calls `errorexit()`

Parameters

- **logr** (*obj*) – A logger object to pass the error message to.
- **name** (*str*) – Name of processing element which caused the error message.
- **path** (*str*) – Missing Path which caused the error message.

Returns None

customlogging.**sect_break** (*logr, level=<property object>*)

Inserts a section break in the logger output.

Parameters

- **logr** (*obj*) – A logger object to pass the section break to.
- **level** (*attr of LogLevelConsts obj, optional*) – Logger level of the section break. Default value: `LogLevelConsts.INFO`

Returns None

customlogging.**setup_logging** (*logr_settings='..//logging.yml', default_level=20*)

Setup logging configuration from a YAML file

Parameters

- **logr_settings** (*str, optional*) – Defines the relative location of the logging configuration file,
- **the root module. Default value** (*from*) – `logging.yml`
- **default_level** (*logging attr, optional*) – Sets the default logging level. Default value: `logging.INFO`

Returns None

docflow.py

BSD © 2018-2019 Science and Technology Facilities Council & contributors

`docflow.py` is a module provided to setup and manage the auto-documentation generation using doxygen and sphinx. Project specific values are extracted from the corresponding `settings.yml` YAML file and the projects structure is determined from the `config.yml` YAML file, each passed to the module via *arguments* (see [Arguments](#)).

Todo:

- Consider Moving doxygen and sphinx template values to `config.yml` YAML file for improved flexibility.
 - Determine the name to assign to: `breathe_project_name`.
-

class docflow.**ProjectDoc** (**kwargs)

An object describing the configuration and settings for the projects documentation generation.

Inherits: project.RepoFlow (obj): Inherited RepoFlow object. See [projectmanager.RepoFlow](#).

Keyword Arguments ****include_dependencies** (bool, optional) – Process and include project dependencies in the generated documentation. Default value: False

generate_automodule (**kwargs)

Generates sphinx reStructuredText auto-module directive

Generates the auto-module directive, in the form:

```
... automodule:: module
... :members:
```

Keyword Arguments

- ****module** (str, optional) – The name of the module to auto-module. Default value: False

- ****indent_size** (int, optional) – Number of spaces in indent. Default value: 3

Returns A line-by-line list of the complete sphinx reStructuredText auto-module directive

Return type list of str

generate_doxyfile (**kwargs)

Generate the doxygen .doxyfile from project derived values and template.

Warning: EXAMPLE_PATH is set with fixed locations and should be modified to be defined in project settings.yml YAML file.

Keyword Arguments

- ****repo_root** (str, optional) – Full resolved path defined by \$REPO_ROOT Default value: ''

- ****name** (str, optional) – The name of the .doxyfile to generate. Default value: ''

- ****doxy_input_paths** (list of str, optional) – List of paths to include as input sources for the generation of documentation. Default value: list()

- ****doxy_source_path** (str, optional) – Path to doxygen source directory which includes common documentation files (*.md) to include in generated documentation. Default value: ''

- ****doxy_build_path** (str, optional) – Full path where to build documentation. Default value: ''

- ****doxy_mainpage_name** (str, optional) – Name of the mainpage to use as index.html in generated HTML documentation. Default value: 'README.md'

- ****doxy_template** (str, optional) – Full path of template file to use for generic .doxyfile configuration options. Default value: ''

- ****doxy_extra_style_sheets** (str, optional) – Extra CSS style sheets used in the generation of HTML pages. Default value: ''

- ****image_path**(*str, optional*) – Full path of images to include in generated documentation. Default value: False
- ****restricted_src**(*bool, optional*) – If set True stops source code from being published in the generated documentation. Default value: True
- ****project_title**(*str, optional*) – The project title used in the generated documentation. Default value: ''
- ****project_version**(*str, optional*) – The project version number, in the form: YYYY.NN used in the generated documentation. Default value: ''
- ****project_logo**(*bool, optional*) – Full path to the logo to use in the generated documentation. Default value: False
- ****project_language**(*str, optional*) – The language of the project being generated, used to optimise the output of the generated documentation. Default value: ''
- ****doxypy_script**(*str, optional*) – Full path of doxypy.py for parsing python code in doxygen. sphinx is preferred over this option. Default value: ''
- ****dot_path**(*str, optional*) – Full path to dot for using graphviz to generate diagrams in generated documentation. Default value: ''

Returns**tuple containing:**

- str: Full path of the generated doxyfile
- str: Full path of the generated xml to be used by breathe to bridge doxygen and sphinx generated documentation.

or: int: -1 on failure.**Return type** tuple**generate_doxymainpage**(***kwargs*)

Generates the doxygen Main Page to act as link between doxygen and sphinx documentation

Parses generated_html_path looking for HTML files where the filename ends with htmlpagefilter and added the file to the generated mainpage, along with the pages title extracted from the HTML page.

Keyword Arguments

- ****doxy_mainpage_dict**(*dict, optional*) – Dictionary of mainpage settings defining the structure and configuration of the mainpage to generate. Default value: dict()
- ****doxy_source_path**(*str, optional*) – Full path to the doxygen source path. Default value: None
- ****generated_html_path**(*str, optional*) – Full path to the generated doxygen generated HTML. Default value: None
- ****doxy_mainpage_title**(*str, optional*) – Title of the generated mainpage which is referenced in the generated documentation. Default value: 'Doxygen Index'
- ****htmlpagefilter**(*str, optional*) – The suffix of the HTML pages to add to the generated mainpage (excluding the file extension). Default value: 'page'

Returns Name of the generated main page**Return type** str

generate_include(kwargs)**

Generates sphinx reStructuredText include directive

Generates the include directive, in the form:

```
.. include:: <include_ref>
```

Keyword Arguments

- ****include_ref** (*str, optional*) – The name of the reference to include. Default value: ''

- ****indent_size** (*int, optional*) – Number of spaces in indent. Default value: 3

Returns A line-by-line list of the complete sphinx reStructuredText include directive

Return type list of str

generate_index_heading(kwargs)**

Generates reStructuredText headings matching sphinx recommended formatting.

see: <http://www.sphinx-doc.org/en/master/usage/restructuredtext/basics.html>

Keyword Arguments

- ****heading_text** (*str, optional*) – The heading string. Default value: False

- ****heading_char** (*str, optional*) – A single character representing the reStructuredText heading level. Default value: #

Valid values: #, *, =, -, ^, "

Returns A line-by-line list of the complete reStructuredText heading

Return type list of str

generate_indices_and_tables(kwargs)**

Generates sphinx reStructuredText Indices and Tables List

Generates the TOC Tree, in the form:

```
=====
Indices and Tables:
=====
* :ref:`genindex`
* :ref:`modindex`
* :ref:`search`
```

Keyword Arguments

- ****indent_size** (*int, optional*) – Number of spaces in indent. Default value: 3

- ****language** (*str, optional*) – Language to determine if module index is included. Included if set to: python. Excluded if set to anything else. Default value: python

Returns A line-by-line list of the complete sphinx reStructuredText Indices and Tables

Return type list of str

generate_sphinx_index_file(kwargs)**

Generates sphinx reStructuredText Index File

Searches for .rst and .md files in the `source_path` and adds them to the generated index file.

If a file matching the `index_name` is found it is **not** added to the generated index file.

If a html directory is found, using the /html/ string, it is added **once** to the generated index file.

Keyword Arguments

- ****source_code_path** (*str, optional*) – Top-Level Path of Source-Code Location. Default value: ''
- ****source_path** (*str, optional*) – Documentation source path to parse for valid files to add to index. Default value: ''
- ****static_path** (*str, optional*) – The name of the sphinx Static Path. Default value: _static
- ****index_name** (*str, optional*) – The name of the index file to generate. Default value: index.rst
- ****readme_name** (*str, optional*) – The name of a valid README file. Could have .rst or .md file extension. Default value: README
- ****src_code_path_list** (*list of str, optional*) – List of source code paths to parse to add to Sphinx documentation. These paths are relative to `source_path`. Default value: list()
- ****max_depth** (*int, optional*) – The maximum depth of the toctree. Default value: 2
- ****indent_size** (*int, optional*) – Number of spaces in indent. Default value: 3
- ****language** (*str, optional*) – Language to determine if module index is included. Included if set to: python. Excluded if set to anything else. Default value: python
- ****header** (*str, optional*) – Common header file to use in generated documentation. Default value: '_static/esdg_header.rst'

Returns

None

`generate_sphinx_modules(**kwargs)`

Generates sphinx reStructuredText Module File

Searches for .py files in locations found in `src_code_path_list`, then passes that list to: `docflow.ProjectDoc.generate_automodule()`

Keyword Arguments

- ****source_code_path** (*str, optional*) – Top-Level Path of Source-Code Location. Default value: ''
- ****source_path** (*str, optional*) – Documentation source path where the <filename>.rst should be generated. Default value: ''
- ****filename** (*str, optional*) – The name of module file to generate. Default value: modules.rst
- ****src_code_path_list** (*list of str, optional*) – List of source code paths to parse to add to Sphinx documentation. Default value: list()
- ****indent_size** (*int, optional*) – Number of spaces in indent. Default value: 3
- ****header** (*str, optional*) – Header file to reference at the top of the generated file. Default value: _static/esdg_header.rst

Returns

None

generate_toctree (kwargs)**

Generates sphinx reStructuredText Table-of-Contents Tree

Generates the TOC Tree, in the form:

```
=====
Index:
=====

..toctree:::
:maxdepth: 2

srcs[0]
srcs[1]
srcs[n]
Doxygen Index <_static/html/index.html://>
```

Keyword Arguments

- ****max_depth** (*int, optional*) – The maximum depth of the toctree. Default value: 2
- ****indent_size** (*int, optional*) – Number of spaces in indent. Default value: 3
- ****srcs** (*list of str, optional*) – List of srcs to include in the toctree. Default value: `list()`
- ****reference_static_html** (*bool, optional*) – Allows the addition of a link to page external to sphinx. Default value: `False`
- ****static_index_text** (*str, optional*) – The human readable string for the reference_static_html link. Default value: `Doxygen Index`
- ****static_index_link** (*str, optional*) – The location of the reference_static_html link, relative to the sphinx top-level source path. Default value: `_static/html/index.html`

Returns A line-by-line list of the complete sphinx reStructuredText Table-of-Contents Tree

Return type list of str

load_settings_from_yaml (kwargs)**

Loads a settings.yml YAML file and returns the ‘documentation’ key.

Keyword Arguments

- ****settings_root** (*str, optional*) – Path to the project’s root settings directory. Default value: ''
- ****settings_filename** (*str, optional*) – Name of settings file to use. Default value: `default_settings.yml`

Returns None

preprocess_sphinxconf (kwargs)**

Preprocessing for the sphinx conf.py File based on the current settings

Checks locations of directories and files exist and copies relevant files to documentation source directory prior to generating the configuration file.

Keyword Arguments

- ****source_path** (*str, optional*) – Documentation source path. Default value: ''
- ****src_code_path** (*str, optional*) – Top-level path of source code to add to sphinx documentation. This path will be searched recursively, directories name: template will be added to a list to be used to add template files to the configuration. Default value: ''
- ****sphinx_source_path** (*str, optional*) – The path of sphinx source code to add in the generated documentation. Default value: ''
- ****sphinx_build_path** (*str, optional*) – The path where sphinx will generate the documentation. Default value: ''
- ****project_name** (*str, optional*) – The project name. Default value: ''
- ****project_version** (*str, optional*) – The project's documentation version. Default value: ''
- ****project_release** (*str, optional*) – The project release. Default value: ''
- ****project_author** (*str, optional*) – The project documentation's author. Default value: ''
- ****project_org** (*str, optional*) – The project's organisation. Default value: ''
- ****project_logo** (*str, optional*) – The name of the project logo to use in the project's documentation. Default value: False
- ****release_uri** (*str, optional*) – The URL for releases to determine the release version. Default value: False
- ****issue_uri** (*str, optional*) – The URL for releases to determine the issue reference. Default value: False
- ****releases_document_name** (*str or list of str, optional*) – The name of the Changelog used by releases. Default value: False
- ****style_sheets** (*str, optional*) – Additional Style-Sheets to use when generating HTML documentation. Default value: False
- ****breathe_project** (*str, optional*) – Breathe project to use when bridging doxygen generated documentation with sphinx. Default value: False
- ****toc_depth** (*int, optional*) – The depth of the toctree used in the generated documentation. Default value: 4
- ****image_path** (*str, optional*) – Path to directory of images to add to the generated sphinx documentation. Files in this directory will be copied to the static_path used by sphinx. Default value: False
- ****source_path** – Path to directory of source files to add to the generated sphinx documentation. Files in this directory will be copied to the static_path used by sphinx. Default value: False
- ****static_path** (*str, optional*) – Path to directory where source files will be copied for the generation of sphinx documentation. Default value: '_static'
- ****doxygen_html_path** (*str, optional*) – Path where doxygen has generated HTML documentation prior to generating the sphinx documentation. These pages will be copied to a 'html' directory in the sphinx static_path for inclusion in the generated sphinx documentation. Default value: None'

- ****sphinx_conf_template**(*str, optional*) – Relative Path, from docflow.py, to the sphinx configuration file template to append to the generated configuration file. Default value: ''
- ****sphinx_make_template**(*str, optional*) – Relative Path, from docflow.py, to the sphinx Makefile file template to append to the generated configuration file. Default value: ''
- ****language**(*str, optional*) – Language to determine if module index is included. Included if set to: python. Excluded if set to anything else. Default value: python
- ****header**(*str, optional*) – Header file to reference at the top of the generated file. Default value: _static/esdg_header.rst

Returns None

process_sphinx_conf_file(kwargs)**

Generates sphinx conf.py File based on the current settings

Completes options from passed values and completes the remaining file by copying the contents from a template file.

Keyword Arguments

- ****source_path**(*str, optional*) – Documentation source path. Default value: ''
- ****src_code_path_list**(*list of str, optional*) – List of source code paths to parse to add to sphinx documentation. Default value: list()
- ****conf_name**(*str, optional*) – The name of sphinx configuration file to generate. Default value: conf.py
- ****project_name**(*str, optional*) – The project name. Default value: ''
- ****project_version**(*str, optional*) – The projects documentation version. Default value: ''
- ****project_release**(*str, optional*) – The project release. Default value: ''
- ****project_author**(*str, optional*) – The project documentation's author. Default value: ''
- ****project_org**(*str, optional*) – The project's organisation. Default value: ''
- ****project_logo**(*str, optional*) – The name of the project logo to use in the project's documentation. Default value: False
- ****release_uri**(*str, optional*) – The URL for releases to determine the release version. Default value: False
- ****issue_uri**(*str, optional*) – The URL for releases to determine the issue reference. Default value: False
- ****releases_document_name**(*str or list of str, optional*) – The name of the Changelog used by releases. Default value: False
- ****style_sheets**(*str, optional*) – Additional Style-Sheets to use when generating HTML documentation. Default value: False
- ****template_file**(*str, optional*) – The name of sphinx configuration template file. file extension. Default value: ''
- ****breathe_project**(*str, optional*) – Breathe project to use when bridging doxygen generated documentation with sphinx. Default value: False

- ****toc_depth** (*int, optional*) – The depth of the toctree used in the generated documentation. Default value: 4
- ****indent_size** (*int, optional*) – Number of spaces in indent. Default value: 4

Returns None

process_sphinx_makefile (**kwargs)

Processes a sphinx Makefile from a supplied template.

Keyword Arguments

- ****build_path** (*str, optional*) – absolute path of the sphinx build location. Default value: ''
- ****make_file_template** (*list of str*) – line-by-line list of Makefile template contents. Default value: ''
- ****makefile** (*str, optional*) – name of the makefile. Default value: Makefile

Returns None

run_doxxygen (**kwargs)

doxygen runner

Keyword Arguments

- ****doxyfile** (*str, optional*) – The full path of doxygen .doxyfile used to generate documentation. Default value: ''
- ****doxy_bin** (*str, optional*) – The name of the bin to use to execute doxygen Default value: 'doxygen'

Returns None

run_sphinx (**kwargs)

sphinx runner

Keyword Arguments

- ****sphinx_source_path** (*str, optional*) – The path of sphinx source to generate documentation. Default value: ''
- ****sphinx_build_path** (*str, optional*) – The path where sphinx will generate the documentation. Default value: ''
- ****builder** (*str, optional*) – builder to invoke. Valid values: html. Default value: html
- ****use_make** (*bool, optional*) – Use the *Makefile* to generate documentation instead of executing directly. Default value: False

Returns 0 on Success

Return type int

set_doxy_paths (**kwargs)

Sets the doxygen source and build paths.

Note: The keyword argument doxy_version should be available on the host system and this value must be included in the *documentation: doxygen: support_tools:* within the configuration file (see [Configuration](#)).

Keyword Arguments

- ****doc_root** (*str, optional*) – Path to projects root docs directory. Default value: ''
- ****doxy_version** (*str, optional*) – version number of doxygen - determines the build path. Default value: ''
- ****clean** (*bool, optional*) – if set to True, removes all existing files from the build directory. Default value: False

Returns**tuple containing:**

- str: Full path of doxygen source location.
- str: Full path of doxygen build location.

Return type tuple**set_image_path** (**kwargs)

Sets the full-path to the images directory to use in generated documentation.

Keyword Arguments

- ****doc_root** (*str, optional*) – Path to projects root docs directory. Default value: ''
- ****image_path** (*str, optional*) – Relative Path, from doc_root, to the project's image directory. Default value: ''

Returns

the full-path to the images directory if found on file-system.

or: bool: False if not found.

Return type str**set_logo** (**kwargs)

Sets the full-path to the logo to use in generated documentation.

Keyword Arguments

- ****doc_root** (*str, optional*) – Path to projects root docs directory. Default value: ''
- ****logo_path** (*str, optional*) – Relative Path, from doc_root, to the project's logo directory. Default value: ''
- ****logo_name** (*str, optional*) – Name of logo file to use. Default value: ''

Returns

the full-path to the logo if found on file-system.

or: bool: False if not found.

Return type str**set_source_path** (**kwargs)

Sets the full-path to the source directory to use in generated documentation.

Keyword Arguments

- ****doc_root** (*str, optional*) – Path to projects root `docs` directory. Default value: ''
- ****source_path** (*str, optional*) – Relative Path, from `doc_root`, to the project's source_path directory. Default value: ''

Returns

the full-path to the source directory if found on file-system

or: bool: `False` if not found.

Return type

`set_sphinx_paths` (***kwargs*)

Sets the `sphinx` source, build and static paths.

Note: The keyword argument `sphinx_version` should be available on the host system and this value must be included in the *documentation: sphinx: support_tools*: within the configuration file (see *Configuration*).

Keyword Arguments

- ****doc_root** (*str, optional*) – Path to projects root `docs` directory. Default value: ''
- ****sphinx_version** (*str, optional*) – version number of `sphinx` to use - determines the build path. Default value: ''
- ****sphinx_static** (*str, optional*) – `sphinx` static directory name. Where existing source files are copied to in order to be included in the generated documentation. Default value: '_static'
- ****clean** (*bool, optional*) – if set to `True`, removes all existing files from the build directory. Default value: `False`

Returns

tuple containing:

- str: Full path of `sphinx` source location.
- str: Full path of `sphinx` build location.
- str: Full path of `sphinx` static location.

Return type

`source_code_publication_msg` (***kwargs*)

Sends a Critical Warning to the Console if Source Code Will be Published in the Documentation

Keyword Arguments

- ****name** (*str, optional*) – Name of project which is publishing source code in the generated documentation. Default value: ''
- ****restricted_flag** (*bool, optional*) – Flag to determine if source-code is being published in the generated documentation. Default value: `True`

Returns

None

environmentsetup.py

BSD © 2018-2019 Science and Technology Facilities Council & contributors

`environmentsetup.py` is a module provided to configure the host environment for each project, setting up environment variables which persist during the execution of the script which defined paths and license references for each tool using the the flow. Specific values are extracted from the corresponding `settings.yml` YAML file and the tool installation structure is determined from the `config.yml` YAML file, each passed to the module via `arguments` (see [Arguments](#)).

Todo:

- Add breathe configuration to `ProjectEnvironment.configure_documentation_tool()`

class environmentsetup.ProjectEnvironment (kwargs)**

An object containing attributes defining the environment variables required for processing a project.

Specific values are extracted from the corresponding `settings.yml` YAML file and the tool installation structure is determined from the `config.yml` YAML file, each passed to the module via `arguments` (see [Arguments](#)).

add_environment_variable(kwargs)**

Adds a system environment variable for the running script.

If the system environment variable already exists this will add the new value as the first value and append the old value using '`:`' as a delimiter.

Keyword Arguments

- ****name** (`str`) – Name of the system environment variable to create/append. Default value: `None`
- ****value** (`str`) – Value to assign to the system environment variable. Default value: `None`
- ****overwrite** (`bool, optional`) – Default value: `False`

Returns `None`**check_if_supported(**kwargs)**

Checks if value in `settings.yml` is supported in `config.yml`

Checks value against a list of `supported_values` and exits with error if not found with reference to the full-path of the failing `settings.yml` YAML used.

Keyword Arguments

- ****value** (`str`) – Default value: `None`
- ****supported_values** (`list of str`) – Default value: `list()`
- ****settings_fileref** (`str`) – Full path, including filename, of settings file used. Default value: `None`

Returns `None`**configure_documentation_tool()**

Configures and validates the system environment variables for running documentation tools.

Supports the following automatic documentation generation tools:

- doxygen

- breathe
- sphinx

Returns None

configure_fpga_vendor_tool()

Configures and validates the system environment variables for running the *FPGA* vendor tool.

Returns None

configure_license(kwargs)**

Configures license environment variables.

Gets configuration from config.yml YAML file (see *Configuration*).

Keyword Arguments ****license_settings** (*dict*) – The license settings from configuration dictionary. Default value: None

Returns None

configure_mode(kwargs)**

Configure tool execution mode.

Provides support for running the tools in 32 or 64 bit modes as well as referencing libraries not supported by the host operating system distribution.

Keyword Arguments

- ****mode** (*str*) – Default value: None
- ****mode_config** (*dict*) – Dictionary defining the mode of running the tool being configured. Default value: None
- ****mode_type** (*str*) – Default value: sim

Returns None

configure_molesim_environment()

Configures and validates the system environment variables for running molesim

Returns None

configure_paths(kwargs)**

Configures system environment paths required for tool execution.

Keyword Arguments ****paths_config** (*dict*) – Dictionary defining the paths and values for the tool being configured. Default value: None

Returns None

get_envvar(kwargs)**

Method to get system environment variable using `os.environ`

If the system environment variable does **not** exist `customlogging.errorexit()` is called.

Keyword Arguments ****variable_name** (*str*) – Name of the system environment variable to get from system. Default value: None

Returns The retrieved system environment variable.

Return type (*str*)

set_args_from_dict(kwargs)**

Sets arguments from a dictionary.

Creates attributes from a dictionary based on key or key [subkey], from the item or items in list found in dictionary[key] or dictionary[key] [subkey]. If using: `from_envvars=True` the attribute will be sourced from the system environment variable.

Keyword Arguments

- ****key** (*str*) – Name of the dictionary key to process. Default value: `None`
- ****subkey** (*str, optional*) – Name of the dictionary sub-key to process. Default value: `None`
- ****dictionary** (*dict*) – Dictionary to extract [key] or [key] [subkey] value from. Default value: `dict()`
- ****from_envvars** (*bool, optional*) – If `True` gets the value from the corresponding system environment variable. Default value: `False`

Returns `None`

`set_attr_from_path(**kwargs)`

Sets an attribute: `name` containing a full-path, without file name.

Keyword Arguments

- ****name** (*str*) – Name of the attribute to set. Default value: `None`
- ****path** (*str*) – Full path, excluding any filenames, of reference to attribute. Default value: `'None'`
- ****create_if_missing** (*bool, optional*) – If `True` Creates the directory structure on the file-system, using `os.makedirs()`. If the directory structure does **not** exist on the file-system. Default value: `False`
- ****force_attr** (*bool, optional*) – If `True` Creates the attribute even if the directory structure does **not** exist on the file-system. Default value: `False`

Returns `None`

`set_envattr(**kwargs)`

Checks to see if the attribute already exists before setting.

Keyword Arguments ****env** (*str*) – Name of the system environment variable to check. Default value: `None`

Returns `None`

`set_path_environ(**kwargs)`

Sets system environment \$path variable.

This performs the equivalent of running:

```
setenv env path
```

If \$env already exists it will append to the existing value:

```
setenv env path:${env}
```

Keyword Arguments

- ****env** (*str*) – Name of the system environment variable name. Default value: `None`
- ****path** (*str*) – System environment variable value. Default value: `None`
- ****delimiter** (*str, optional*) – Delimiter to use between multiple environment variable values Default value: `':'`

- ****overwrite** (bool, optional) – If True overwrite existing value instead of appending. Default value: False

Returns None

`setattr_from_envvar(**kwargs)`

Sets attribute from system environment variable.

Gets the value from corresponding `$envs`` and sets attribute matching the system environment variable name with the value retrieved.

Keyword Arguments ****envs** (str) – Name of the system environment variable to process.
Default value: None

Returns None

`fpgavendor_iface.py`

BSD © 2018-2019 Science and Technology Facilities Council & contributors

`fpgavendor_iface.py` is a module to handle the generation of FPGA projects and interfacing with `vunit_iface`, to include the compilation of FPGA vendor simulation modules based on tool version and FPGA device family.

`class fpgavendor_iface.FpgaProject(**kwargs)`

`add_ip(**kwargs)`

Keyword Arguments

- ****vunit_obj** (obj) – A `vunit_iface.VunitProject` object. Default value: `self.vu`
- ****project_file** (str) – Absolute path to project file.
- ****rebuild_project** (bool, optional) – If True rebuild existing project. Default value: False

Returns None

`backup_project(**kwargs)`

Backup project using timestamp.

Appends time stamp to the project directory in the form: `__%Y%m%d%H%M%S` and uses `shutil.copytree()` to backup the project. Then cleans the original directory (using `shutil.rmtree()`) and remaking the location using: `os.makedirs()`

Keyword Arguments ****project_path** (str) – Absolute path to project root.

Returns None

`create_quartus_project(**kwargs)`

Creates a quartus project using supplied settings.

Copy constraints from `.qsf` file line-by-line directly, ignoring blank and commented lines, into project file replacing any instance of `$REPO_PATH` with `$env(REPO_ROOT)`. Leaves the original constraints file untouched, which should have the same effect as having sourced the constraints file.

Keyword Arguments

- ****project_name** (str, optional) – Name of project file to generate. Default value: 'project'

- ****build_path** (*str*) – Absolute path to build location for generated project
- ****target_language** (*str, optional*) – Target default language for the generated project. Default value: 'VHDL_2008'
- ****top_level_entity** (*str*) – Top-level HDL entity name.
- ****hdl_files** (*list of tuples*) – containing HDL libraries and absolute path to HDL file.
- ****tb_hdl_file** (*list of tuples*) – containing HDL libraries and absolute path to Test Bench HDL file.
- ****ip_files** (*list of str*) – List of absolute paths fof IP files to add to project.
- ****constraint_files** (*list of str*) – List of absolute paths of constraints to add to project.

Returns None

create_vivado_project (**kwargs)

Creates a vivado project using supplied settings.

Keyword Arguments

- ****project_name** (*str, optional*) – Name of project file to generate. Default value: 'project'
- ****build_path** (*str*) – Absolute path to build location for generated project
- ****target_language** (*str, optional*) – Target default language for the generated project. Default value: 'VHDL'
- ****top_level_entity** (*str*) – Top-level HDL entity name.
- ****hdl_files_dict** (*dict*) – Dictionary of HDL libraries (keys) and list of absolute HDL files.
- ****ip_files** (*list of str*) – List of absolute paths fof IP files to add to project.
- ****constraint_files** (*list of str*) – List of absolute paths of constraints to add to project.

Returns None

get_project_file ()

Gets the absolute path of the project file.

Returns Absolute path of project file. None if not found.

Return type str

fpgavendor_iface.**generate_timestamp** ()

Generates a Unix 32 Bit Time Stamp from the systems time as an integer value.

Returns Timestamp as an integer for conversion to a VHDL *unsigned std_logic_vector(31 downto 0)*.

Return type str

fpgavendor_iface.**resolve_tool_version** (**kwargs)

Resolves the tool_version based on vendor

Keyword Arguments

- **tool_version** (*str*) – Version of tool to resolve.

- **vendor** (*str, optional*) – Vendor name. Valid values: 'altera', 'xilinx'. Default 'xilinx'

Returns The resolved tool_version when successful, otherwise False

Return type str

fpgavendor_iface.**run_ip_generate**(**kwargs)

Executes the Quartus qsys-generate

Executes the qsys-generate to generate Quartus IP.

Keyword Arguments

- ****exe** (*str, optional*) – Executable to run. Default value: 'qsys-generate'
- ****ip_file** (*str*) – Absolute path to IP file to generate.
- ****output_path** (*str*) – Absolute path where output files are generated.
- ****synth** (*bool, optional*) – generate for synthesis if True otherwise generate for simulation. Default value: True
- ****synth_language** (*str, optional*) – HDL language used to generate synthesis files. Valid values: 'VHDL' or 'VERILOG'. Default value: 'VERILOG'
- ****sim_language** (*str, optional*) – HDL language used to generate simulation files. Valid values: 'VHDL' or 'VERILOG'. Default value: 'VHDL'
- ****family** (*str, optional*) – FPGA Family. Default value: False
- ****device** (*str, optional*) – FPGA Device. Default value: False
- ****clean** (*bool, optional*) – Cleans IP Path Prior to Generating IP. Default value: False

Returns None

fpgavendor_iface.**run_ip_setup_simulation**(**kwargs)

Executes the Quartus run-ip-setup-simulation

Executes the run-ip-setup-simulation to gather simulation setup commands for all Vendor IP libraries used in current design.

Keyword Arguments

- ****exe** (*str, optional*) – Executable to run. Default value: 'ip-setup-simulation'
- ****project_file** (*str*) – Absolute path to project file to process.
- ****output_path** (*str*) – Absolute path where output files are generated.

Returns None

fpgavendor_iface.**run_quartus_sh**(**kwargs)

Runs quartus_sh to execute compilation for standard HDL simulation libraries.

Keyword Arguments

- ****quartus_bin** (*str, optional*) – Name of executable to run quartus. Default value: 'quartus_sh'
- ****script_mode** (*bool, optional*) – Run quartus_sh in script mode. Default value: False
- ****** –

- ****tool** (*str*) – Name of the tool to run. Should be derived from:
simulator_class = SIMULATOR_FACTORY.select_simulator()
simname = simulator_class.name
- ****language** (*str, optional*) – Valid options: 'verilog' or 'vhdl'. Default value: 'vhdl'
- ****modelsim_path** (*str*) – Absolute path to the version of Modelsim to use to compile standard HDL libraries.
- ****output_path** (*str*) – Absolute path where to compile standard HDL libraries.
- ****tcl_file_name** (*str*) – Absolute path to the tcl script used by vivado
- ****tcl_args** (*str, optional*) – Additional positional arguments needed to execute tcl_file_name Default value: None
- ****gui** (*bool, optional*) – Runs Quartus in GUI Mode. Default value: False
- ****project_file** (*str*) – Absolute path to project file.

Returns None

`fpgavendor_iface.run_vivado(**kwargs)`

Runs vivado in specified mode.

When running in 'gui' mode, the tcl_file keyword argument is the project file to open.

Note: The shell=True in check_call is important in windows where vivado is just a bat file.

Keyword Arguments

- ****vivado_bin** (*str, optional*) – Name of executable to run vivado. Default value: 'vivado'
- ****mode** (*str, optional*) – Name of the mode to run. Valid values: 'batch', 'tcl' or 'gui'. Default value: 'batch'
- ****tcl_file_name** (*str*) – Absolute path to the tcl script used by vivado when running in 'tcl' mode, and the project file to open when running in 'gui' mode.
- ****tcl_args** (*str, optional*) – Additional positional arguments needed to execute tcl_file_name Default value: None

Returns None

`helpers/funcs.py`

BSD © 2018-2019 Science and Technology Facilities Council & contributors

`funcs.py` is a helpers module to provide functions commonly used throughout.

`class funcs.Const`

Allows attributes to be treated like constants where they can be set one time only.

Raises ConstError if attribute already exists.

`exception ConstError`

`funcs.clean_path(**kwargs)`

Cleans given path, by removing and recreating empty path.

Keyword Arguments `**path` (*str*) – Absolute path to clean.

Returns None

`funcs.copy_files_from_dir(src_path, dst_path)`

Copy files from source directory to destination directory.

Uses `shutil.copy2` to copy files recursively from one directory to another directory.

Parameters

- `src_path` (*str*) – Full-path of the source directory.
- `dst_path` (*str*) – Full-path of the destination directory.

Returns None

`funcs.get_kwarg(arg, kwargs, default)`

Finds arg in kwargs and returns the value. If arg is not found return the provided default value.

Parameters

- `arg` (*str*) – Name of argument to extract
- `kwargs` (*dict*) – Dictionary of keys, values to find and return `arg` value from.
- `default` – The value to assign if `arg` is not a key in `kwargs`

Returns `default`

`funcs.readfile_as_list(full_path)`

Takes a full-path to file and returns the contents as a list.

Parameters `full_path` (*str*) – Full path, including file name, of the file to read from.

Returns Line-by-line list of file contents.

Return type (list)

`funcs.replace_tag_with_attr_value(obj, tag)`

Replaces a <TAG> with a corresponding attribute value.

Looks for <TAG> (enclosed in <>) in tag string passed to the function, and if found returns a string with the tag replaced by the value as `obj.tag`.

If the attribute exists but is not populated with a value an “empty” string ‘ ’ is returned. This allows all <TAG> options in the layout configuration to be optional.

Parameters

- `obj` (*obj*) – Object to assign replaced <TAG> as attribute.
- `tag` (*str*) – string to check for sub-strings enclosed in <> .

Returns An empty string if corresponding attribute for the <TAG> is **not** found; or the corresponding attribute if found; or the original <TAG> if anything else.

Return type (str)

`funcs.set_kwargs(obj, kwargs)`

Sets attributes to specified existing object.

Parameters

- `obj` (*str*) – name of the object to assign attribute(s).
- `kwargs` (*dict*) – dictionary of key, values, where key is the attribute and value is the value to assign

Returns None

`funcs.strip_tag(tag)`

Removes the < and > from tag and returns the lowercase string enclosed.

Parameters `tag` (`str`) – UPPERCASE tag enclosed in < and >

Returns lowercase TAG with < and > stripped.

Return type (`str`)

`funcs.validate_file(f, touch=False)`

Checks the given file exists on the file-system. If touch is True, create the file if it is missing.

Parameters

- `f` (`str`) – Full path, including file name, of the file to validate.
- `touch` (`bool, optional`) – If set creates an empty file if not found on the file-system.
Default value: False

Returns True on success, False otherwise.

`funcs.writefile_as_list(full_path, contents)`

Takes a list and writes contents line-by-line to file.

Parameters

- `full_path` (`str`) – Full path, including file name, of the file to write.
- `contents` (`list`) – Line-by-line list of contents to write.

Returns None

projectmanager.py

BSD © 2018-2019 Science and Technology Facilities Council & contributors

`projectmanager.py` is a module provided to setup, validate and execute source-code retrieval from externally hosted repositories. Project specific values are extracted from the corresponding `settings.yml` YAML file and the projects structure is determined from the `config.yml` YAML file, each passed to the module via `arguments` (see *Arguments*).

```
class projectmanager.ProjectDependency(repo_root, name, category, url, local_path, remote_path, remote_rev, required_vhdl_libs=[], vunit_default=False, top_level=False, board_name=None, board_settings=None, family=None, device=None, **kwargs)
```

Processes project dependencies.

Takes a dictionary and converts keys to attributes before parsing configuration to construct all attributes required to describe a Dependency Object

Parameters

- `repo_root` (`str`) – The resolved `$REPO_ROOT` system environment variable.
Required by: `projectmanager.ProjectDependency.layout_to_dir` and
`projectmanager.ProjectDependency.prune_path_list`
- `name` (`str`) – Name of dependency
- `category` (`str`) – The dependency's category
- `url` (`str`) – Root URL to remote repository location for the dependency

- **local_path** (*str*) – Local path of the *working copy* for the dependency
- **remote_path** (*str*) – Remote path, from the `url` for the dependency
- **remote_rev** (*str*) – Specific repository revision for the dependency
- **required_vhdl_libs** (*list of str, optional*) – List of required HDL libraries required by the dependency. Default value: `list()`
- **vunit_default** (*bool, optional*) – VUnit dependency flag. Default value: `False`
- **top_level** (*bool, optional*) – Project Top-level dependency flag. Default value: `False`
- **board** (*str, optional*) – Target board for dependency. Default value: `None`
- **board_settings** (*str, optional*) – Settings file name for target board for dependency. Default value: `None`
- **family** (*str, optional*) – Target FPGA Family for HDL dependency. Default value: `None`
- **device** (*str, optional*) – Target FPGA Device for HDL dependency. Default value: `None`

Keyword Arguments

- ****repo_config_dict** (*dict*) – The layout dictionary which defines the projects layout within the repository and working copy on the local file-system. Required by `projectmanager.ProjectDependency.layout_to_dir` Default value: `dict()`
- ****lib_append_categories** (*list of str*) – Default value: `list()`
- ****bitbucket_username** (*str, optional*) – Default value: `None`
- ****tag_replacement_dict** (*dict*) – Dictionary of required tag replacement fields required by `projectmanager.ProjectDependency.layout_tag_attr_replace`. This is variable based on category Default value: `dict()`
- ****retag_layout** (*bool, optional*) – True

get_lib_from_name (**kwargs)

Determines the VHDL library name from project name.

Determines the VHDL library name from the project name, ignoring if suffix already exists. the suffix is only appended if the category exists in the `lib_append_categories` list

Keyword Arguments

- ****name** (*str*) – The project name being processed. Default value: ''
- ****category** (*str*) – The category of the project being processed. Default value: ''
- ****lib_append_categories** (*list of str, optional*) – List of categories to append lib_suffix from config.yml configuration file (see `categories`:). If the category is **not** in this list the suffix will **not** be appended. Default value: `list()`.
- ****lib_suffix** (*str, optional*) – The library suffix to append. Default value: '_lib'

Returns The name of the VHDL library

Return type (*str*)

layout_tag_attr_replace(kwargs)**

Replaces <TAG> with corresponding attribute

Looks for <TAG> (enclosed in <>) in tag string passed to the function, and if found returns a string with the tag replaced by the value in the self.<TAG> attribute.

If the attribute exists but is not populated with a value an “empty” string ‘’ is returned. This allows all <TAG> options in the layout configuration to be optional. Although self.name should always have a value as it is also used to determine filenames in the directory structure.

Keyword Arguments ****tag** (str) – string to check for sub-strings enclosed in <>.

Returns An empty string if corresponding attribute for the <TAG> is **not** found; or the corresponding attribute if found; or the original <TAG> if anything else.

Return type (str)

layout_to_dir(kwargs)**

Takes a single top-level and creates the directory and file structure as a list.

This layout structure is expected to be defined in the layout_dict keyword passed to the module.

Uses top_refs list to look for a reference to indicate the top reference string, which is used to populate self._top_dirs, this can then be used to create attributes for top_level reference directories.

Keyword Arguments

- ****layout_dict** (dict) – Default value: dict ()
- ****repo_root** (str) – Default value: None
- ****top_refs** (list of str) – Default value: list ()
- ****replace_tags** (bool) – Default value: True

Returns None

prune_path(kwargs)**

Prunes path down towards root_path.

Takes a path and prunes that path until prune_to is found, if root_path is reached it means that prune_to was not found in the path.

Returns path up to and including prune_to, or False if not found.

Keyword Arguments

- ****path** (str) – Path to prune. Default value: None
- ****prune_to** (str) – Prune down to this path. Default value: None
- ****root_path** (str) – If root_path is reached the prune fails. Default value: None

Returns The found pruned path. The *bool*: False is returned if root_path is reached without finding the prune criteria.

Return type (str)

prune_path_list(kwargs)**

Prunes list of paths based on keyword matching.

Keyword Arguments

- ****path_list** (list of str) – List of paths to prune. Default value: None
- ****keyword** (str) – Keyword which **must** exist in path_list item for prune. Default value: ‘’

- ****root_path** (*str*) – If root_path is reached the prune fails. Default value: None

Returns A list of pruned paths.

Return type (list of str)

retag_path (**kwargs)

Re-tags path(s).

Keyword Arguments

- ****term** (*str*) – Term to retag.
- ****tag** (*str*) – Tag value to replace term with.
- ****paths** (*str or list of str*) – absolute path(s) to retag. This assumes the absolute path is in the form: \$REPO_ROOT/<TERM>/xx/xx/xx/<TERM> where the second term will be replaced with tag.
- ****repo_root** (*str*) – The actual path of the system environment variable \$REPO_ROOT

Returns List of retagged absolute paths. Empty list () if no repo_root supplied.

Return type list of str

static set_top_refs (*category, name, tool_version*)

Parameters

- **category** (*str*) – category to determine the top-level reference to return.
- **name** (*str*) – returned if category is *not* boards or vendor_ip
- **tool_version** (*str*) – returned if category *is* boards or vendor_ip

Returns list of str

static top_dir_lookup (**kwargs)

Maps supported top-level directory names to known values for specified usage throughout

Keyword Arguments ****dir_name** (*str*) – Name of directory name to attempt to map.

Returns Mapped name if matched. dir_name if *not* matched.

Return type str

class projectmanager.RepoFlow (**kwargs)

Parses the project settings file for repository_config key and processes locations found under the key. This provides enough information to construct the local working_copy path using repo_root inherited from projectenvironment.ProjectEnvironment and the URL of the remote repository.

Inherits: projectenvironment.ProjectEnvironment (obj): Inherited RepoFlow object. See projectenvironment.projectenvironment.

Username is assumed to be the same for each repository top-level URL (using self.svn_username, self.bitbucket_username and/or self.git_username inherited from projectenvironment.ProjectEnvironment)

construct_local_path (**kwargs)

Constructs the local path for the local working-copy.

Constructed by joining root and path.

Parameters

- ****root** (*str*) – The top-level root. Usually derived from the \$REPO_ROOT environment variable. Default value: None
- ****path** (*str*) – The path, derived from *subversion:*, but with the *subpath:* removed. This allows the switching between *trunk*, *branches* and *tags* to be managed by the repository client. Default value: None

Returns Full path of the local working-copy path.

Return type (*str*)

construct_remote_path (**kwargs)

Constructs the remote path in the externally hosted repository.

Determines if the URL is *git* and/or *bitbucket* from *urlparse.netloc*. Uses *urlparse* to construct URL, where *username* is constructed manually at the front of *urlparse.netloc*.

Uses *posixpath* to construct path portion of URL by joining *urlparse.path*, *path* and *subpath*.

Parameters

- ****url** (*str*) – The top-level root URL. See *subversion:*. Default value: None
- ****path** (*str*) – The path. See *subversion:*. Default value: None
- ****subpath** (*str*) – The sub-path. See *subversion:*. Default value: None

Returns

- (*str*): Full path of the remote URL.
- (*str*): Username for remote URL.
- (*str*): Repo type <'*subversion*' or '*git*'>. Determined from URL.

Return type tuple containing

get_category_from_path (**kwargs)

Gets *category*: from *path*.

The first directory in the *path* string represents the category.

Keyword Arguments

- ****path** (*str*) – Default value: ''
- ****category_mapping** (*dict*, optional) – Category mapping (see *categories:*). Default value: *dict*().
- ****supported_categories** (*list of str*, optional) – List of supported categories from *config.yml* configuration file (see *categories:*). Default value: *list*().

Returns the *category* extracted from *path*.

Return type (*str*)

get_contrib_lib_from_path (**kwargs)

Gets *contrib_lib*: from *path*.

Assumes (i know!) that *contrib_lib* exists between the *category* and *name*. For a valid *contrib_lib* to exist the number of elements in *path* should be = 3.

Keyword Arguments

- ****name** (*str*) – The project name being processed. Default value: ''
- ****path** (*str*) – The path of the project on the file-system. Default value: ''

- ****category_mapping** (*dict*, *optional*) – Category mapping (see *categories*:). Default value: *dict* () .

Returns the contrib_lib extracted from path.

Return type (str)

process_repository_config (**kwargs)

Process repository configuration for current project

- Keyword Arguments** ****repository_config** (*dict*) – Dictionary of Repository Configuration for Repository Type extracted from settings.yaml YAML file.

Returns A list of processed *ProjectDependency* objects.

Return type (list of obj)

class projectmanager.VendorIpDependency (**kwargs)

Vendor IP is an Vendor IP object containing methods and attributes required for processing vendor_ip

Keyword Arguments

- ****repo_root** (str) – Absolute path to the system environment \$REPO_ROOT.
- ****master_vendor_ip** (*obj*) – A project dependency object for the *master* vendor_ip dependency for the project.
- ****vendor** (str) – FPGA Vendor. Used to determine vendor_ip locations. Valid values: 'xilinx' and altera'. Default value: 'xilinx'
- ****tool_version** (str) – FPGA Tool Version. Used to determine vendor_ip locations.
- ****family** (str) – FPGA Family. Used to determine vendor_ip locations.
- ****device** (str) – FPGA Device. Used to determine vendor_ip locations.
- ****ip_dict** (*dict*) –
- ****settings_file** (str) – Absolute path to settings YAML file, used in logs.

resolved_master_tags (**kwargs)

Keyword Arguments

- ****paths** (str, or list of str) – Absolute path to resolve tags
- ****vendor** (str) – FPGA Vendor. Used to determine vendor_ip locations. Valid values: 'xilinx' and altera'. Default value: 'xilinx'
- ****tool_version** (str) – FPGA Tool Version. Used to determine vendor_ip locations.
- ****family** (str) – FPGA Family. Used to determine vendor_ip locations.
- ****device** (str) – FPGA Device. Used to determine vendor_ip locations.

Returns List of absolute paths with tags resolved.

Return type list of str

setup.py

BSD © 2018-2019 Science and Technology Facilities Council & contributors

helpers/version.py

BSD © 2018-2019 Science and Technology Facilities Council & contributors

`version.py` is a helpers module provided to handle public version numbering which follows the PEP440 guidelines.

Note: The `__version__` uses the `version.Version` (defined in this module), therefore is used towards the end of this module.

class `version.Version(major, minor, micro, prerelease=”, svn_rev=”, disable_svn_logging=False)`

Creates a Class with methods to construct and fetch PEP440 Public Version Numbering

Creates an initial PEP440 Public Version Identifier from the supplied parameters after validating the prerelease parameter,

Parameters

- **major** (*int*) – Representing the Major Version Number (changes affecting execution method)
- **minor** (*int*) – Representing the Minor Version Number (bugfixes)
- **micro** (*int*) – Representing the Micro Version Number (correction of typos/release notes)
- **prerelease** (*int, optional*) – Addition Pre-Release Indicator. Valid values: a, b, rc, where: a = alpha; b = beta; and rc = release candidate
- **svn_rev** (*str, optional*) – SVN Revision Number
- **disable_svn_logging** (*bool*) – Do not include SVN output in logs. Default value: False

get_version()

Method to get the string representation of the version number.

Returns String of Version Number

set_version(major, minor, micro, pre)

Method to set the string representation of a Version Number.

Parameters

- **major** – Integer Value Representing the Major Version Number (changes affecting execution method)
- **minor** – Integer Value Representing the Minor Version Number (bugfixes)
- **micro** – Integer Value Representing the Micro Version Number (correction of typos/release notes)
- **pre** – Optional Addition Pre-Release Indicator... a = alpha b = beta rc = release candidate

Returns string

`version.about(modname, ver, revision)`

Method to Create an About String, to display Method Name and Version/Rev

Parameters

- **modname** (*str*) – Module Name
- **ver** (*str*) – Version Number, in the form: MAJOR.MINOR.MICRO
- **revision** (*str*) – SVN Revision Number

Returns

Return type str

vunit_iface.py

BSD © 2018-2019 Science and Technology Facilities Council & contributors

vunit_iface.py is a module to handle interfacing and utilising external VUnit module.

See [VUnit Documentation](#).

class vunit_iface.VUnitProject (**kwargs)

VUnit Project is a VUnit object used to configure and execute simulation test-cases.

Keyword Arguments

- ****simulation_path** (str) – Absolute simulation root path for the VUnit project.
- ****sim_pre_compiled_libs** (str) – Absolute path to the location for precompiled simulation libraries.
- ****fpga_vendor** (str) – FPGA Vendor. Used to determine build and precompiled library locations. Valid values: 'xilinx' and altera'. Default value: 'xilinx'
- ****fpga_toolversion** (str) – FPGA Tool Version. Used to determine build and pre-compiled library locations.
- ****sim_version** (str) – Simulation Version. Used to determine build and precompiled library locations.
- ****hdl_lib_file_dict** (dict, optional) – A dictionary containing library keys and absolute paths to HDL files for each library. Default value: dict ()
- ****tb_hdl_lib_file_dict** (dict, optional) – A dictionary containing library keys and absolute paths to test-bench HDL files for each library. Default value: dict ()
- ****args** (obj, optional) – argparse object containing arguments passed to script. If one is not supplied it will be generated here.
- ****use_osvvm** (bool, optional) – Use OSVVM Components. Default value False
- ****use_verification_components** (bool, optional) – Use VUnit Verification Components. Default value False
- ****settings_file** (str) – Absolute path to settings YAML file, used in logs.
- ****clean_precompiled_libs** (bool, optional) – If True clean precompiled standard simulation libraries for the current project. Default value: False
- ****msim_64bit** (bool, optional) – If False uses -32bit flag to execute Modelsim.
- ****hdl_sim_libs** (dict) – Dictionary of Vendor Standard HDL Libraries to add to VUnit.
- ****modelsim_installdir** (str, optional) – Absolute path to the Modelsim install directory. Used when compiling altera standard libraries.
- ****repo_root** (str) – Absolute path to the resolved system environment variable \$REPO_ROOT.

vu

obj – The VUnit object.

add_hdl_files(**kwargs)

Adds HDL Files to corresponding library.

Keyword Arguments ****hdl_lib_file_dict** (*dict*) – A dictionary containing library keys and absolute paths to files for each library.

Returns None

add_standard_libraries(**kwargs)

Adds Standard Simulation Libraries to VUnit

This method is derived from : [VUnit supplied example](#)

Keyword Arguments

- ****vunit_obj** (*obj, optional*) – A VUnit object. Default value: `self.vu`
- ****standard_library_path** (*str, optional*) – Absolute path to the location for precompiled simulation libraries. Default value: `self.sim_pre_compiled_libs_path`
- ****hdl_sim_libs** (*dict*) – Dictionary of Vendor Standard HDL Libraries to add to VUnit.

Returns True when successful, False when unsuccessful.

Return type bool

add_vivado_sim_dependencies(**kwargs)

Add Vivado simulation dependencies to VUnit object

Keyword Arguments

- ****vivado_path** (*str*) – Absolute path to Vivado.
- ****src_paths** (*list of str, optional*) – List of absolute paths to search for dependencies relative to `vivado_path`. Default value: `['data/verilog/src']`
- ****src_files** (*list of str, optional*) – List of source file dependencies. Default value: `['glbl.v']`
- ****glbl** (*bool, optional*) – Include glbl dependency. Default value: False
- ****glbl_lib** (*str, optional*) – Library to add glbl to. Default value: `'xil_defaultlib'`
- ****vunit_obj** (*obj, optional*) – VUnit object. Default value: `self.vu`

Returns True if successful, False if unsuccessful

Return type bool

compile_project_ip(**kwargs)

Compiles FPGA Project Specific IP Simulation Libraries

Keyword Arguments

- ****project_file** (*str*) – Absolute path to project file to parse.
- ****simulation_path** (*str, optional*) – Absolute path to the location for simulation path Default value: `self.simulation_path`
- ****project_ip_subpath** (*str, optional*) – Name of project_ip libraries sub-path. Default value: `'project_ip'`
- ****msim_setup_script** (*str, optional*) – Filename of `.tcl` to compile Vendor IP simulation files in Modelsim. Default value: `'mentor/msim_setup.tcl'`

- ****top_level_lib** (str, optional) – Top-level library to add Vendor IP simulation file to in Modelsim, if False the library name will match the filename, as configured in the generated .qip file. Default value: False

Returns None

compile_standard_libraries (**kwargs)

Compiles Standard Simulation Libraries

This method is derived from : [VUnit supplied example](#)

Keyword Arguments

- ****sim_pre_compiled_libs** (str, optional) – Absolute path to the location for precompiled simulation libraries. Default value: self.sim_pre_compiled_libs_path
- ****standard_lib_subpath** (str, optional) – Name of standard library sub-path. Default value: 'standard'
- ****fpga_vendor** (str) – FPGA Vendor. Valid values: 'xilinx' or 'altera'.
- ****settings_file** (str) – Absolute path to settings YAML file, used in logs.
- ****clean** (bool, optional) – If True cleans the standard library path. Default value: False
- ****msim_64bit** (bool, optional) – If False uses -32bit flag to execute Modelsim. Default value: False
- ****hdl_sim_libs** (dict) – Dictionary of Vendor Standard HDL Libraries to add to VUnit.
- ****modelsim_installdir** (str, optional) – Absolute path to the Modelsim install directory. Used when compiling altera standard libraries.

Returns True when successful, False when unsuccessful.

Return type bool

configure_gui (**kwargs)

Pre-processing of additional simulation init file to use when GUI mode is enabled.

Keyword Arguments

- ****sim_init_script** (str) – Absolute path to initialisation file for GUI mode.
- ****repo_root** (str) – Replacement str for \$REPO_ROOT.

Returns None

static is_verilog_header (filename)

Checks if filename indicates the file is a verilog header file.

Parameters **filename** (str) – Filename to check if it matches the criteria of a verilog header file.

Returns True if a verilog header file, otherwise False

Return type bool

read_compile_order (**kwargs)

Read the vendor_ip simulation compile order file and filter out duplicate files

Keyword Arguments ****filename** (str) – Absolute path to compile order filename to process.

Returns list of str, set, list of str

Return type tuple containing

resolve_gui_init_script (**kwargs)

Parses Simulation GUI Initialisation Script

There appears to be an issue with Modelsim directly using \$env(REPO_ROOT) in scripts passed from VUnit to Modelsim, so this workaround creates a file with REPO_ROOT resolved and uses the created resolved file instead:

Keyword Arguments

- ****sim_init_script** (str) – Absolute path to initialisation file to resolve.
- ****repo_root** (str) – Replacement str for \$REPO_ROOT.

Returns

Return type str

setup_simulation_options (**kwargs)

Sets up the compile and sim options.

Keyword Arguments

- ****glbl** (bool, optional) – Include glbl dependency. Default value: False
- ****glbl_lib** (str, optional) – Library to add glbl to. Default value: 'xil_defaultlib'

Returns None

vunit_iface.**tb_cfg_encode** (tb_cfg)

Encodes a VUnit test-case dictionary configuration to a string to pass to VUnit Test-Case

String is passed to VHDL test-bench file using the encoded_tb_cfg generic.

Parameters **tb_cfg** (dict) –

Returns str

Electronic System Design Group

1.1.1.4 Arguments

Arguments to pass to FPGAFlow.

Required

--config

The configuration YAML file describing:

- configuration of the host system
- source-code repository layout

See *Configuration* for description.

--settings

The Settings YAML file describing:

- Libraries and Tools Used by the current project
- Project Specific Settings

See [Settings](#) for description.

Optional

--checkout_enabled

Enables checkout of source code from repository. Defaults to: False.

To use:

```
--checkout_enabled
```

--headless

Headless Flag for Forcing GUI Based Options to False. Used to ensure Continuous Integration environments execute unimpeded by external user input. Defaults to: False.

```
--headless
```

--skip_xml2vhdl

Prevents the XML2VHDL Generation Script from being executed. Defaults to: False.

To use:

```
--skip_xml2vhdl
```

Warning: This Argument should be used with caution. It assumes existing generated .vhd exists for the project to compile. The resulting compilation **may** be out-of-date if changes to the memory-map have been made to any .xml files in the project.

--open_gui

Opens project in GUI. Overwritten by --headless, which will prevent any GUI from running.

fpga

Opens the project in either quartus or vivado.

sim

Opens the project in simulation for each enabled test-case.

```
--open_gui <fpga|sim>
```

--clean

Cleans Output Paths Generated by FPGAFLOW.

all

Cleans **all** generated output paths excluding 'precompiled_sim' which must be called explicitly.

fpga

Cleans the project for the current vendor, tool_version and project_name. Any existing FPGA Vendor project in the build path will be backed up, by appending a date/time stamp to the build folder and a new project will be generated by the script. If not used as an argument the script will use the existing project.

ip

Cleans the projects vendor_ip enabled IP generated paths for the current vendor, tool_version.

precompiled_sim

Cleans the pre-compiled libraries for the current vendor, tool_version, sim_vendor and sim__version for under the root path defined by \$SIM_PRE_COMPILED_LIBS_PATH.

Warning: This may fail if the user does not have the correct permissions to operate on this directory.

sim

Cleans the projects compiled simulation libraries.

```
--clean all
```

Electronic System Design Group

1.1.1.5 Configuration

The script is configured using a YAML file passed using the `--config` argument (see *Arguments*).

```
python ./docflow.py --config <CONFIG.YML>
```

The description of the YAML file is described below.

Tag Substitution

The configuration file operates using tag substitution with values set in the corresponding *Settings* file. Tags are all uppercase enclosed in `<>` characters.

```
<UPPERCASE_TAG>
```

where the UPPERCASE tag represents a key in the *Settings* which will be substituted when the script is executed. The `repository_required` fields in the configuration file should include all tag substitution keys.

Sections

`repository:`

The repository section configures the expected directory structure of each supported category for code stored in the externally hosted repository.

Listing 1: complete example of `config.yml` entry for `repository` section

```
repository:
  required:
    - name
    - contrib_lib
    - vendor
    - tool_version
    - sim_vendor
    - sim_version
  categories:
    - boards
    - library
    - tools
    - vendor_ip
  category_mapping:
    library: libraries
  lib_append_categories:
    - boards
    - library
  boards_layout:
    - boards:
        - <VENDOR>:
          - <NAME>:
            - <TOOL_VERSION>:
              - constraints:
              - docs:
                - common:
```

(continues on next page)

(continued from previous page)

```

        - logo:
        - doxygen:
          - <DOXY_VERSION>:
            - source:
        - sphinx:
          - <SPHINX_VERSION>:
            - build:
            - source:
              - _static:
              - _templates:
        - scripts:
          - python:
          - tcl:
        - settings:
          - <NAME>.yml
        - simulation:
          - testbenches:
            - EXCLUDE
        - src:
          - vhdl:
            - EXCLUDE
            - generated:
          - vhdl_packages:
          - xml:
library_layout:
  - libraries:
    - <CONTRIB_LIB>:
      - <NAME>:
        - constraints:
        - <VENDOR>:
          - pre_flow:
          - post_module:
          - post_flow:
          - pre_synth:
          - pre_opt:
        - docs:
          - common:
            - logo:
          - doxygen:
            - <DOXY_VERSION>:
              - source:
          - sphinx:
            - <SPHINX_VERSION>:
              - source:
                - _static:
                - _templates:
        - netlists:
  - scripts:
    - tcl:
    - python:
  - settings:
    - <NAME>.yml
  - simulation:
    - testbenches:
      - EXCLUDE
  - src:
    - vhdl:

```

(continues on next page)

(continued from previous page)

```

        - EXCLUDE
        - generated:
        - vhdl_packages:
        - xml:

tools_layout:
- tools:
- <NAME>:
- docs:
- common:
    - logo:
- doxygen:
    - <DOXY_VERSION>:
    - source:
- sphinx:
    - <SPHINX_VERSION>:
    - build:
    - source:
        - _static:
        - _templates:
- scripts:
- python:
    - <NAME>-<ORG>:
    - <NAME>:

```

required:

This provides a list of required field from the *Settings* file required to execute the script correctly. The script expects each of the list items to be populated in the settings YAML file ready for *Tag Substitution*.

categories:

This provides a list of categories supported by the script. The layout of each repository item is defined by its category and the *<CATEGORY>_layout:* settings defined in the configuration YAML file. The list of categories is used by *Tag Substitution* to determine the *<CATEGORY>_layout:*.

category_mapping:

If the category is stored in the repository using a different reference category_mapping can be used to map the different category name to the category name.

lib_append_categories:

The convention employed by this script is to name libraries matching their name in the repository. This section allows categories to be listed where _lib should be appended to the name.

Note: Names which already have _lib included in their name in the repository will NOT have _lib re-appended.

<CATEGORY>_layout:

A layout should be defined for each category in the *categories*: list.

This defines the layout for all files stored in the corresponding repository location. *Tag Substitution* is used to fully construct the <CATEGORY>_layout and it is expected that all tags are listed in the *repository_required* section of the configuration file.

contributors:

Listing 2: complete example of config.yml entry for contributors section

```
contributors:
  contrib_lib_list:
    - common
    - lib_ox
    - lib_stfc
```

contrib_lib_list:

A list of contributors for source-code and development within the project. The values here define the ownership and responsibility of items stored in the repository.

Note: It is expected that modifications, enhancements and bugfixes should be undertaken by the owner of the source-code in question.

fpga:

Listing 3: complete example config.yml entry for fpga using xilinx and altera

```
fpga:
  supported_vendors:
    - xilinx
    - altera
  xilinx:
    license:
      xilinxd_license_file:
        - 2100@<LICENSE.SERVER1>
    paths:
      root_path: /path_to/xilinx/<TOOL_VERSION>/
      root_name: vivado_rootdir
      additional_paths:
        installdir: Vivado/<TOOL_VERSION>
        xilinx_vivado: Vivado/<TOOL_VERSION>
    add_to_path:
      - Vivado/<TOOL_VERSION>/bin
      - Vivado_HLS/<TOOL_VERSION>/bin
  family:
```

(continues on next page)

(continued from previous page)

```

- kintex_ultrascale
devices:
- xcku040-ffvaa1156-2-e
- xcku040-fbva676-1-c
boards:
- avnet_ku040
- itpm_v1_1
tools:
- 2016.2
- 2016.3
- 2018.1
- 2018.3
default_lib:
xil_defaultlib

altera:
license:
lm_license_file:
- 1800@<LICENSE.SERVER1>
mode:
supported_modes:
- 0
- 1
env_name: quartus_64bit
ld_library_path_0:
ld_library_path_1:
paths:
root_path: /path_to/Altera/prime/<TOOL_VERSION>
root_name: quartus_installdir
additional_paths:
quartus_rootdir: quartus
qsys_rootdir: qsys/bin
add_to_path:
- quartus/bin
- nios2eds/bin
- quartus/sopc_builder/bin
- hld/bin
family:
- arria_10
- stratix_10
family_mappings:
arria_10: 'Arria 10'
stratix_10: 'Stratix 10'
devices:
- 10AS066N2F40I2SGES
- 1SX280LU3F50I3XG
boards:
- a10_soc_dev_kit
- xpressgx_s10fh200g
tools:
- pro/17.0
- pro/17.1
- pro/18.0
- pro/18.1
- std/17.0
- std/17.1
- std/18.0

```

(continues on next page)

(continued from previous page)

- std/18.1

supported_vendors:

List of supported simulation vendors. Each entry in this list should have a corresponding entry under *supported_vendors*::

<FPGA VENDOR>:**license:**

A dictionary of key value pairs defining the license system environment variable name and values to assign when configuring the system environment. Values can be a single value, or a list of values. For xilinx:

Listing 4: example config.yml entry for fpga license

```
xilinx:
  license:
    xilinxd_license_file:
      - 2100@<LICENSE.SERVER1>
      - 2100@<LICENSE.SERVER2>

# or:

xilinx:
  license:
    xilinxd_license_file:
      2100@<LICENSE.SERVER1>
```

paths:

A dictionary of key value pairs defining path based system environment variables and values to assign when configuring the system environment. Supported keys:

root_path: Path to <FPGA VENDOR> root installation path.

Note: Tag Substitution works here, where <TOOL_VERSION> is defined in the --settings YAML file.

root_name: Name of system variable to create with reference to **root_path**:

add_to_path: A list of sub-paths relative to **root_path**: to append to the system \$PATH variable.

```
xilinx:
  paths:
    root_path: /path_to/xilinx/<TOOL_VERSION>/
    root_name: vivado_rootdir
    additional_paths:
      installdir: Vivado/<TOOL_VERSION>
      xilinx_vivado: Vivado/<TOOL_VERSION>
    add_to_path:
```

(continues on next page)

(continued from previous page)

- Vivado/<TOOL_VERSION>/bin
- Vivado_HLS/<TOOL_VERSION>/bin

Will result in the following system environment variables to be modified or created when `tool_version: 2018.3` is set in the `tool_version:` file as an example:

```
setenv VIVADO_ROOTDIR '/path_to/xilinx/2018.3'
setenv INSTALLDIR '/path_to/xilinx/2018.3'
setenv XILINX_VIVADO '/path_to/xilinx/2018.3'
setenv PATH '/path_to/xilinx/2018.3/Vivado/2018.3/bin':${PATH}
setenv PATH '/path_to/xilinx/2018.3/Vivado_HLS/2018.3/bin':${PATH}
```

`mode:`

A dictionary of key value pairs defining execution mode of *FPGA* tool. Support keys with example values:

supported_modes: A list of supported modes which are accepted by the system environment variable named by `mode:` under `env_name:`

env_name: Name of the system environment variable which sets the tools mode of execution.

ld_library_path_<MODE_IN_SUPPORTED_MODES>: Path to append to `LD_LIBRARY_PATH` which points to location of non-standard libraries required for the correct operation of the simulation tool when running in <MODE_IN_SUPPORTED_MODES> bit mode.

Listing 5: example config.yml entry for fpga mode

```
altera:
  mode:
    supported_modes:
      - 0
      - 1
  env_name: quartus_64bit
  ld_library_path_0:
  ld_library_path_1:
```

Will result in the following system environment variables to be modified or created, using `tool_mode: 1` is set in the `tool_mode:` as an example:

```
setenv QUARTUS_64BIT 1
```

`family:`

A list of *FPGA* families supported by *FPGAFlow*. The names here should match the corresponding name as it appears in the *FPGA* vendor's project file.

`devices:`

A list of *FPGA* devices supported by *FPGAFlow*. The names here should match the corresponding part number as it appears in the *FPGA* vendor's project file.

boards:

A list of hardware platforms to which can be targeted by FPGAFlow.

Note: The values here will be used by *Tag Substitution* to populate the <NAME> and corresponding fields when processing the `settings.yml` YAML file (see *Settings*) and when determining the `boards_layout`: directory structure.

tools:

A list of *FPGA* tool versions supported by FPGAFlow.

Note: The values here will be used by *Tag Substitution* to populate <TOOL_VERSION> when processing the `settings.yml` YAML file (see *Settings*) and when setting up the system environment and paths required to allow FPGAFlow to execute the correct versions of *FPGA* vendor's tools. This also determines then "build" directory structure and which `vendor_ip` to use in the project.

default_lib:

The name of the default library used by the *FPGA* vendor.

simulation:

Listing 6: complete example `config.yml` entry for simulation using modelsim

```
simulation:
  supported_vendors:
    - modelsim
  modelsim:
    license:
      mglsl_license_file:
        - 1717@<LICENSE.SERVER1>
        - 1717@<LICENSE.SERVER2>
    paths:
      root_path: /path_to/modelsim/<SIM_VERSION>/modeltech
      root_name: model_tech
      additional_paths:
        modelsim_installdir: bin
    add_to_path:
      - bin
  mode:
    supported_modes:
      - 32
      - 64
    env_name: mti_vco_mode
    ld_library_path_32:
      - /path_to/non-standard/lib32
    ld_library_path_64:
      - /path_to/non-standard/lib64
  xilinx:
```

(continues on next page)

(continued from previous page)

```

sim_libs:
  - 'unisims_ver'
  - 'unimacro_ver'
  - 'unifast_ver'
  - 'secureip'
  - 'xpm'
  - 'unisim'
  - 'unimacro'
  - 'unifast'
  - 'simprims_ver'
verilog_sim_libs: None
vhdl_sim_libs: None
altera:
  sim_libs: None
  verilog_sim_libs:
    - 'altera_ver'
    - 'lpm_ver'
    - 'sgate_ver'
    - 'altera_mf_ver'
    - 'altera_lnsim_ver'
    - 'fourteennm_ver'
    - 'fourteennm_ctl_ver'
    - 'cyclone10gx_ver'
    - 'cyclone10gx_hip_ver'
    - 'cyclone10gx_hssi_ver'
    - 'tennm_ctl_ver'
    - 'tennm_ver'
    - 'twentynm_ver'
    - 'twentynm_hip_ver'
    - 'twentynm_cssi_ver'
  vhdl_sim_libs:
    - 'altera'
    - 'lpm'
    - 'sgate'
    - 'altera_mf'
    - 'altera_lnsim'
    - 'fourteennm'
    - 'fourteennm_ctl'
    - 'cyclone10gx'
    - 'cyclone10gx_hip'
    - 'cyclone10gx_hssi'
    - 'tennm_ctl'
    - 'tennm'
    - 'twentynm'
    - 'twentynm_hip'
    - 'twentynm_hssi'

```

supported_vendors:

List of supported simulation vendors. Each entry in this list should have a corresponding entry under *supported_vendors*:

<SIM TOOL VENDOR>:

supported_tools:

A list of supported versions. The items in this list are used to differentiate between installed versions of the tool on the host system. Therefore it is expected that each version listed is installed on the system using the value in the list to define the version of the tool. This allows multiple tools to be installed for device and legacy support.

license:

A dictionary of key value pairs defining the license system environment variable name and values to assign when configuring the system environment. Values can be a single value, or a list of values. For modelsim:

Listing 7: example config.yml entry for simulation license

```
modelsim:
  license:
    mgls_license_file:
      - 1717@<LICENSE.SERVER1>
      - 1717@<LICENSE.SERVER2>

# or:

modelsim:
  license:
    mgls_license_file:
      1717@<LICENSE.SERVER1>
```

paths:

A dictionary of key value pairs defining path based system environment variables and values to assign when configuring the system environment. Supported keys:

root_path: Path to <SIM TOOL VENDOR> root installation path.

Note: *Tag Substitution* works here, where <SIM_VERSION> is defined in the --settings YAML file.

root_name: Name of system variable to create with reference to `root_path`:

add_to_path: A list of sub-paths relative to `root_path`: to append to the system \$PATH variable.

Listing 8: example config.yml entry for simulation paths

```
modelsim:
  paths:
    root_path: /path_to/modelsim/<SIM_VERSION>/modeltech
    root_name: model_tech
    additional_paths:
      modelsim_installldir: bin
    add_to_path:
      - bin
```

Will result in the following system environment variables to modified or created when `sim_version: 10.6e` is set in the `sim_version:` file as an example:

```
setenv MODEL_TECH '/path_to/modelsim/10.6e/modeltech'
setenv MODELSIM_INSTALLDIR '/path_to/modelsim/10.6e/modeltech/bin'
setenv PATH '/path_to/modelsim/10.6e/modeltech/bin':${PATH}
```

mode:

A dictionary of key value pairs defining execution mode of simulation tool. Support keys with example values:

supported_modes: A list of supported modes which are accepted by the system environment variable named by *mode*: under *env_name*:

env_name: Name of the system environment variable which sets the tools mode of execution.

ld_library_path_<MODE_IN_SUPPORTED_MODES>: Path to append to LD_LIBRARY_PATH which points to location of non-standard libraries required for the correct operation of the simulation tool when running in <MODE_IN_SUPPORTED_MODES> bit mode.

Listing 9: example config.yml entry for simulation mode

```
modelsim:
  mode:
    supported_modes:
      - 32
      - 64
    env_name: mti_vco_mode
    ld_library_path_32:
      - /path_to/non-standard/lib32
    ld_library_path_64:
      - /path_to/non-standard/lib64
```

Will result in the following system environment variables to be modified or created, using *sim_mode*: 32 is set in the *sim_mode*: as an example:

```
setenv MTI_VCO_MODE 32
setenv LD_LIBRARY_PATH '/path_to/non-standard/lib32':${LD_LIBRARY_PATH}
```

xilinx:

sim_libs:

A list of standard verilog and VHDL library mappings for adding to simulations. These are precompiled once and should be available in the path defined by *SIM_PRE_COMPILED_LIBS_PATH*

verilog_sim_libs:

A list of standard verilog library mappings for adding to simulations. These are precompiled once and should be available in the path defined by *SIM_PRE_COMPILED_LIBS_PATH*

Note: For xilinx this can be unset, i.e. left empty: verilog_sim_libs:

vhdl_sim_libs:

A list of standard VHDL library mappings for adding to simulations. These are precompiled once and should be available in the path defined by [SIM_PRE_COMPILED_LIBS_PATH](#)

Note: For `xilinx` this can be unset, i.e. left empty: `vhdl_sim_libs`:

altera:**sim_libs:**

A list of standard verilog and VHDL library mappings for adding to simulations. These are precompiled once and should be available in the path defined by [SIM_PRE_COMPILED_LIBS_PATH](#)

Note: For `altera` this *must* be unset, i.e. left empty: `sim_libs`:

verilog_sim_libs:

A list of standard verilog library mappings for adding to simulations. These are precompiled once and should be available in the path defined by [SIM_PRE_COMPILED_LIBS_PATH](#)

vhdl_sim_libs:

A list of standard VHDL library mappings for adding to simulations. These are precompiled once and should be available in the path defined by [SIM_PRE_COMPILED_LIBS_PATH](#)

vhdl:

Listing 10: example

vhdl:

documentation:

Configuration for documentation tools.

Listing 11: complete example of config.yml entry for contributors section

documentation:

- required:**
 - doxy_version
 - dot_version
 - sphinx_version
- supported_languages:**

(continues on next page)

(continued from previous page)

```

- vhdl
- python
doxygen:
  supported_tools:
    - 1.8.14
  paths:
    root_path: /path_to/doxygen-<DOXY_VERSION>/
    root_name: doxygen_installdir
    add_to_path:
      - bin
  internal_references:
    doxypypy_script: ../../../../scripts/shell/doxypypy/py_filter
    doxy_template: templates/doxygen/<DOXY_VERSION>/templates/doxy_template.
→Doxyfile
  doxy_extra_style_sheets:
    - templates/doxygen/<DOXY_VERSION>/stylesheets/regtables.css
dot:
  supported_tools:
    - 2.38.0
    - 2.40.1
  paths:
    root_path: /path_to/graphviz-<DOT_VERSION>/bin
    root_name: dot_path
sphinx:
  supported_tools:
    - 1.8.2
  paths:
    internal_references:
      sphinx_conf_template: templates/sphinx/<SPHINX_VERSION>/templates/conf.py
      sphinx_make_template: templates/sphinx/<SPHINX_VERSION>/templates/Makefile

```

required:

This provides a list of required field from the *Settings* file required to execute the script correctly. The script expects each of the list items to be populated in the settings YAML file ready for *Tag Substitution*.

supported_languages:

A list of languages supported by the script for the auto-generation of documentation.

doxygen:

Configuration for doxygen tool used to auto-document VHDL files.

support_tools:

A list of supported versions.

Note: Versions of these tools should be available on the host system and one of these values must be included in the

settings file (see [Settings](#)).

paths:

Configuration of the paths for the installation directories for doxygen.

root_path: Path to doxygen root installation path.

Note: *Tag Substitution* works here, where <DOXY_VERSION> is defined in the --settings YAML file.

root_name: Name of system variable to create with reference to root_path:

add_to_path: A list of sub-paths relative to root_path: to append to the system \$PATH variable.

internal_references: A list of reference names and values for addition specific items to the doxygen configuration. This includes references to additional scripts, template files and a list of css files.

Note: internal_references: are relative to: \$REPO_ROOT/tools/fpgaflow/scripts/python/

Tag Substitution works here, where <DOXY_VERSION> is defined in the --settings YAML file.

sphinx:

Configuration for sphinx tool used to auto-document python files.

Note: Sphinx and its dependencies is installed in the the python virtual environment and managed by pipenv

support_tools:

A list of supported versions.

Note: Versions of these tools should be available on the host system via pipenv virtual environment and one of these values must be included in the settings file (see [Settings](#)).

paths:

internal_references: A list of reference names and values for addition specific items to the sphinx configuration. This includes references template files.

Note: internal_references: are relative to: \$REPO_ROOT/tools/fpgaflow/scripts/python/

Tag Substitution works here, where <DOXY_VERSION> is defined in the --settings YAML file.

dot:

Configuration for graphviz tool used by doxygen for the generation of diagrams.

support_tools:

A list of supported versions.

Note: Versions of these tools should be available on the host system and one of these values must be included in the settings file (see *Settings*).

paths:

Configuration of the paths for the installation directories for graphviz.

root_path: Path to graphviz root installation path

Note: Tag Substitution works here, where <DOT_VERSION> is defined in the --settings YAML file.

root_name: Name of system variable to create with reference to root_path:

environment:

Configuration options for the user environment, to prevent user based locations and information being stored in source-code repositories.

Listing 12: complete example of config.yml entry for environment section

```
environment:  
  required:  
    - REPO_ROOT  
    - PIPENV_SHELL  
    - BITBUCKET_USERNAME  
    - GIT_USERNAME  
    - SVN_USERNAME  
    - SIM_PRE_COMPILED_LIBS_PATH  
  exclude_keywords:  
    - 'build/'  
    - 'synopsys'  
    - 'aldec'  
    - 'cadence'  
    - '.svn'  
    - 'template'  
    - '.Xil'  
    - '.cache'  
    - '.hw'  
    - '.ip_user_files'  
    - 'scripts'  
    - 'ref_design'
```

(continues on next page)

(continued from previous page)

```
- 'bin'
- 'docs'
- 'settings'
- 'constraints'
- '.settings'
- 'modelsim_'
- 'vunit_output'
```

required:

This provides a list of required system environment variables required to successfully execute the script correctly. The script expects each of the list items to be declared prior to the script executing and are validated when the script is executed.

REPO_ROOT

Sets the top-level root path where all projects/libraries will be checked out to and processed from.

PIPENV_SHELL

Path to the executable for the shell pipenv should run.

BITBUCKET_USERNAME

The username used to access user controlled private bitbucket *cloud* hosted repositories.

GIT_USERNAME

The username used to access user controlled private git *server* hosted repositories (which may be bitbucket).

SVN_USERNAME

The username used to access user controlled private subversion repositories.

SIM_PRE_COMPILED_LIBS_PATH

The root path to precompiled Modelsim libraries.

exclude_keywords:

A list of exclude keywords to use throughout the flow. Files or directories containing any term in the list will automatically be excluded from the project build.

Electronic System Design Group

1.1.1.6 EXCLUDE Files

In addition to *exclude_keywords*: defined in *Configuration* provision to add exclusions on a path basis is included via the use of EXCLUDE files. If an EXCLUDE file is placed in a directory it will be parsed, line-by-line, for terms to exclude.

Warning: The exclusion is very aggressive, a line containing only v would exclude all .vhd, .v and any file or path containing the character v from the search. Therefore it is recommended that file names are included on a line-by-line basis, including a / prefix to ensure no other files with similar names are excluded.

Note:

- Wildcard(s) *, % are **not** supported.
 - Search terms are case sensitive.
-

Electronic System Design Group

1.1.1.7 Installation

FPGAFlow has been developed for use in a Linux based environment.

Prerequisites

Required Software

The following software is required:

–	Version
python	>= 2.7.14
pipenv	>= 2018.05.18
svn	>= 1.9.0
git	>= 1.8.0

Python Modules

Python Modules are handled by pipenv and stored in: ./scripts/python/fpgaflow/Pipfile

Module	Version
breathe	4.11.0
colorlog	3.1.4
doxypypy	0.8.8.6
gitpython	2.1.11
logging	0.4.9.6
lxml	4.3.0
numpy	1.16.0
pygments	2.2.0
pyyaml	3.13
releases	1.6.1
sphinx-rtd-theme	0.4.2
sphinx	1.8.2
svn	0.3.46
vunit_hdl	4.0.8

Additional Modules

The modules below can be installed from `$REPO_ROOT/tools/<MODULE>/scripts/python/<MODULE>-<ORG>/dist/` using the `*.tar.gz` sdist source file.

`pipenv_installer.py` is provided in `$REPO_ROOT/tools/<MODULE>/scripts/python/utils` to aid the installation of additional modules from `$REPO_ROOT/tools`. See [Utils](#).

Module	Version
xml2vhdl-ox	0.1.16

Installed Tools

FPGAFlow assumes at least one version of either of the following tools are installed on the system where FPGAFlow is executed from:

- Xilinx Vivado
- Intel PSG Quartus Prime

FPGAFlow assumes at least one version of each of the following tools are installed on the system where FPGAFlow is executed:

- Modelsim
- doxygen
- graphviz

Paths and licensing for these tools are configured in the `config.yaml` file passed to FPGAFlow using the `--config` argument (see [Configuration](#) for details).

Required Environment Variables

The following Environment Variables are required by FPGAFlow. These ensure that no personal locations are stored in version management systems (see: [required](#)):

REPO_ROOT Sets the top-level root path where all projects/libraries will be checkout out to and processed from.

BITBUCKET_USERNAME The username used to access user controlled private git *cloud* hosted repositories.

GIT_USERNAME The username used to access user controlled private git *server* hosted repositories.

SVN_USERNAME The username used to access user controlled private subversion repositories.

PIPENV_SHELL Path to the executable for the shell pipenv should run.

SIM_PRE_COMPILED_LIBS_PATH The root path to precompiled Modelsim libraries.

Installation Instructions

1. Checkout/Clone FPGAFlow and xml2vhdl from their repositories:

```
git clone https://$BITBUCKET_USERNAME@bitbucket.org/mjroberts/fpgaflow.git $REPO_ROOT/  
↳ tools/fpgaflow  
git clone https://$BITBUCKET_USERNAME@bitbucket.org/ricch/xml2vhdl.git $REPO_ROOT/  
↳ tools/xml2vhdl
```

2. Create or Modify Configuration YAML file to add tool paths, versions and license paths to: \$REPO_ROOT/tools/fpgaflow/scripts/python/fpgaflow/config/<YOUR_CONFIG>.yml (see *Configuration* for details).
3. Create or Modify Settings YAML file to define project: \$REPO_ROOT/tools/fpgaflow/settings/<YOUR_SETTINGS>.yml (see *Settings* for details).
4. Navigate to path where FPGAFlow will be executed.
5. Install the python virtual environment using pipenv_installer.py (see *pipenv_installer.py*) ensuring the version of python meets the *Prerequisites*.

```
pipenv_installer.py xml2vhdl-ox fpgaflow-stfc
```

6. Run FPGAFlow using pipenv in shell or run:

```
pipenv shell  
python ./projectflow.py --config ./config/<YOUR_CONFIG>.yml --settings ../../.../  
↳ settings/<YOUR_SETTINGS>.yml  
## Or:  
pipenv run python ./projectflow.py --config ./config/<YOUR_CONFIG>.yml --settings ../../.../  
↳ settings/<YOUR_SETTINGS>.yml
```

Links

- <https://docs.pipenv.org>
- <https://vunit.github.io/documentation.html>

Electronic System Design Group

1.1.1.8 Known Issues

1. Script fails to determine top-level dependency if the top-level is in the boards category.
2. Vendor IP Common Wrapper files are not parsed for vendor_ip without a <IPSUBCAT>.

Electronic System Design Group

1.1.1.9 Directory Layouts

Root Directory Processing

FPGAFlow operates on directory structures as defined in the *Configuration* YAML file. See `<CATEGORY>_layout:`.

The root directory of each layout is automatically determined by the script, if modifying the directory layouts the following rules **must** be applied to the layouts:

- The identifier to determine the root directory of libraries is the `<NAME>` tag.
- The identifier to determine the root directory of boards is the `<TOOL_VERSION>` tag.

Note: `vendor_ip` directory layout processing is handled separately.

FPGAFlow will parse the root directory for each enabled location and automatically add the first level of directories below the root directory. These are used to determine the locations of design files required to run designs through FPGAFlow.

First Level Directories

The following mappings are hard-coded in the script. See `projectmanager.ProjectDependency.top_dir_lookup`.

`constraints`

Directories matching any of following names are deemed to be the location of `constraints`:

- constraints
- constr
- constrs

`docs`

Directories matching any of following names are deemed to be the location of `docs`:

- docs
- doc
- documents

- documentation

netlists

Directories matching any of following names are deemed to be the location of **netlists**:

- netlists
- net
- nets

scripts

Directories matching any of following names are deemed to be the location of **scripts**:

- scripts
- script

settings

Directories matching any of following names are deemed to be the location of **settings**:

- settings
- setting

simulation

Directories matching any of following names are deemed to be the location of **simulation**:

- simulation
- sim
- sims

src

Directories matching any of following names are deemed to be the location of **src**:

- src
- srcs
- sources

Electronic System Design Group

1.1.1.10 Settings

The script uses settings using a YAML file passed using the `--settings` argument (see [Arguments](#)).

The description of the YAML file is described here.

```
python ./projectflow.py --settings <SETTINGS.YML>
```

Sections

<CATEGORY>:

The category of the project from list of `categories:` in the configuration file (see [Configuration](#)). This defines the repository layout of the project (see `<CATEGORY>_layout:`).

`name:`

Name of the project.

Note: The value here is used by [Tag Substitution](#) replacing the `<NAME>` tags in the [Configuration](#) file.

`contrib_lib:`

Name of the contributor's library. This defines the owner of the project and is used in the path to the location/structure of the project as it is stored in the externally hosted repository.

Note: `contributors:` defines a list of all of the contributors. The value here is used by [Tag Substitution](#) replacing `<CONTRIB_LIB>` tags in the [Configuration](#) file.

`top_level:`

Name of the top-level entity HDL component. This can be a `str` or `list` and the entity name should appear in the HDL filename. If no top-levels are supplied the script will search for files in library (determined from `name:`) for filenames which contain `name:` and one term from: `['top_', '_top']`. If none are found the script will exit.

Used by `projectflow` in conjunction with `board_id:` to generate the FPGA Vendor project name, if no `board_id:` is supplied:

```
<TOP_LEVEL>
```

where `<TOP_LEVEL>` is the first item in `top_level:` list (or the str of `top_level:` is supplied as a single entry).

The project name can be overwritten by `project_name_override:`

`top_level_tb_entity:`

Name of the top-level test-bench used when executing VUnit simulations.

vendor:

Name of the *FPGA* vendor the project is targeting.

Note: The value here is used by *Tag Substitution* replacing <VENDOR> tags in the *Configuration* file.

family:

Name of the *FPGA* family the project is targeting.

Note: The value here is used by *Tag Substitution* replacing <FAMILY> tags in the *Configuration* file.

tool_version:

Version of the *FPGA* vendor tool to use for the generation of the project.

Note: The value here is used by *Tag Substitution* replacing <TOOL_VERSION> tags in the *Configuration* file.

tool_mode:

Value to set the corresponding system environment variable to define the *FPGA* vendor tool operating mode. Sets either 32 or 64 bit operation.

device:

FPGA vendor defined device identifier to use for the generation of the project.

board_id:

A hex represented 32 bit number to insert into the *FPGA* project via a top-level generic named: g_board_id. This will be converted into a integer.

Listing 13: Generated Quartus settings file entry for board_id

```
set_parameter -name g_board_id 0
```

Listing 14: board_id generic

```
generic(
    g_board_id      : integer := 0
);
```

This can then be used in user logic using:

Listing 15: board_id user logic constant

```
constant c_board_id      : std_logic_vector(31 downto 0) := std_logic_vector(to_
→unsigned(g_board_id, 32));
```

Note: This is a **board** only option.

board_timestamp_enabled:

The script will generate a Unix 32 bit timestamp for when the corresponding *FPGA* project is generated by the script. If this option is enabled using True the timestamp will be inserted via a top-level generic named: g_board_timestamp.

Listing 16: Generated Quartus settings file entry for board_timestamp

```
set_parameter -name g_board_timestamp 0
```

Listing 17: board_timestamp generic

```
generic(
    g_board_timestamp      : integer := 0
);
```

This can then be used in user logic using:

Listing 18: board_timestamp user logic constant

```
constant c_board_timestamp      : std_logic_vector(31 downto 0) := std_logic_vector(to_
→unsigned(g_board_timestamp, 32));
```

Note: This is a **board** only option.

board:

Predefined hardware to target when generating the project. If supplied projectflow will use this value to generate the *FPGA* Vendor project name in the form:

```
<BOARD>_<TOP_LEVEL>
```

where <BOARD> is the *board_id*: name and <TOP_LEVEL> is the first item in *top_level*: list (or the str of *top_level*: is supplied as a single entry).

The project name can be overwritten by *project_name_override*:

board_settings:

Name of the settings file to parse when associating board with design.

Warning: Options in this file will overwrite options in the calling settings file.

`project_name_override:`

Option to override the automatically generated project name with a custom name.

`sim_vendor:`

Simulation vendor to use when running simulations.

`sim_version:`

Version of the simulation tool to use when running simulations.

Note: The value here is used by *Tag Substitution* replacing <SIM_VERSION> in the *Configuration* file.

`sim_mode:`

Value to set the corresponding system environment variable to define the simulation tool operating mode. Sets either 32 or 64 bit operation.

`sim_init_script:`

Name of the simulation initialisation script to usw when running simulations in GUI mode.

Note: Use: \$env (REPO_ROOT) to avoid including user specific absolute paths in this file.

`use_glbl:`

If True adds glbl dependencies to xilinx simulations.

Note: This is a xilinx only option and is ignored for altera projects.

`vunit_args:`

Allows options from `settings.yml` YAML file to be passed to VUnit as if they are command-line arguments. For detailed information see: [VUnit Documentation](#).

Listing 19: example settings.yml entry for vunit_args

```

vunit_args:
  version: False
  list: False
  files: False
  log_level: warning
  output_path: simulation/vunit_output
  test_patterns:
    - None
  keep_compiling: True
  num_threads: 2
  elaborate: False
  verbose: False
  xunit_xml: xunit_report.xml
  coverage:
  unique_sim: False
  exit_0: False
  no_color: False
  quiet: True
  xunit_xml_format: 'bamboo'
  dontCatchExceptions: False
  export_json: ''
  with_attributes:
  without_attributes:
  compile: False
  fail_fast: False

```

version:

Reports the version being used. See: [vunit_cli](#)

Warning: If True This will report the version number and exit, not running VUnit. The script will raise a warning log if this option is set.

list:

Lists the test-cases being used *without* executing the simulation. See: [vunit_cli](#)

Warning: If True This will list the test-cases being used by simulation and exit, not running VUnit. The script will raise a warning log if this option is set.

files:

Lists the HDL files being used *without* executing the simulation. See: [vunit_cli](#)

Warning: If True This will list the files being used by simulation and exit, not running VUnit. The script will raise a warning log if this option is set.

`log_level:`

Sets the log-level for simulation. See: [vunit_cli](#)

`output_path:`

Sets the output_path for generated simulation files. See: [vunit_cli](#)

`test_patterns:`

List of test-cases or test-case patterns to simulate. – `None` will **not** run any test-cases.

`keep_compiling:`

If `True` keep compiling HDL if errors are found. Otherwise will exit on first error. See: [vunit_cli](#)

`num_threads:`

Number of threads to use running simulations. See: [vunit_cli](#)

`elaborate:`

Use elaborate. See: [vunit_cli](#) See: [vunit_cli](#)

`verbose:`

Run in verbose mode. See: [vunit_cli](#)

`xunit_xml:`

Name of the XML Report file. See: [vunit_cli](#)

`coverage:`

Use full coverage. See: [vunit_cli](#)

`unique_sim:`

Use unique simulations. See: [vunit_cli](#)

`exit_0:`

Exit with code 0 on errors. See: [vunit_cli](#)

no_color:

Disables colour logging when True. See: [vunit_cli](#)

xunit_xml_format:

Sets the format for the generated xunit_xml report file. Set to 'bamboo'. See: [vunit_cli](#)

dontCatchExceptions:

From VUnit Documentation: “Let exceptions bubble up all the way. Useful when running with “python -m pdb”.”.

See: [vunit_cli](#)

export_json:

From VUnit Documentation: “Export project information to a JSON file.”

json file will be generated in the output_path:. Leave blank to skip generation. See: [vunit_cli](#)

with_attributes:

List of test-cases or test-case to simulate which **do** have these attributes. Leave blank or have a single item of '' to ignore.

From VUnit Documentation: “Only select tests with these attributes set”

without_attributes:

List of test-cases or test-case to simulate which **do not** have these attributes. Leave blank or have a single item of '' to ignore.

From VUnit Documentation: “Only select tests without these attributes set” See: [vunit_cli](#) See: [vunit_cli](#)

compile:

When ` True compiles HDL and exits. See: [vunit_cli](#)

fail_fast:

When True stop on first failed test. See: [vunit_cli](#)

repository_config:

Defines location in externally hosted source-code repository for the top-level project and each dependency required to execute [projectmanager](#)

git:

Listing 20: example settings.yml entry for repository_config

```
repository_config:  
  git:  
    <NAME>:  
      enabled: True  
      vunit_default: False  
      url: <https://<GIT_BITBUCKET_URL/>  
      path: tools/xml2vhdl  
      branch: master  
      tag:  
      required_vhdl_libs: []
```

Warning: *Tag Substitution* has not been tested here. <> Should be replaced by actual values.

<NAME>:

The name of the project or project dependency.

enabled: Location is processed by the script if set to: True, otherwise skipped if set to: False.

vunit_default: Location is processed by Vunit if set to: True, otherwise skipped by Vunit if set to: False.

url: Top-Level URL of externally hosted git repository hosted on bitbucket.

Note: This is the clone URL from bitbucket with the username@ portion removed. username@ will be generated by *projectmanager* from \$BITBUCKET_USERNAME system environment variable.

path: Path of location on the local file-system. Should match project path based on *categories*: and <CATEGORY>_layout: for the project or project dependency being defined.

branch: Specific git branch to use.

tag: Specific git tag to use.

Note: tag: is **not** used in the context of using FPGAFlow to clone git repositories. The user is expected to manage tags and branches for development purposes after the repository has been cloned.

required_vhdl_libs: List of required VHDL libraries, names matching corresponding <NAME> entry in *git*: or *subversion*:

Note: required_vhdl_libs: is currently only used to ensure the VHDL libraries used by XML2VHDL script are included and enabled in *projectflow*.

subversion:

Listing 21: example settings.yml entry for repository_config

```
repository_config:
  subversion:
    <NAME>:
      enabled: True
      vunit_default: True
      url: <https://<SVN_REPO_ROOT_URL/>>
      path: <CATEGORY>/<CONTRIB_LIB>/<NAME>
      subpath: trunk
      rev: HEAD
      required_vhdl_libs: []
```

Warning: Tag Substitution has not been tested here. <> Should be replaced by actual values.

<NAME>:

The name of the project or project dependency.

enabled: Location is processed by the script if set to: True, otherwise skipped if set to: False.

vunit_default: Location is processed by Vunit if set to: True, otherwise skipped by Vunit if set to: False.

url: Top-Level URL of externally hosted SVN repository.

path: Path of location in repository. Should match project path based on *categories*: and <*CATEGORY*

subpath: 'trunk', 'branches/<BRANCH_NAME>' or 'tag/<TAG_NAME>' for the project or project dependency being defined.

rev: Specific SVN revision or HEAD.

required_vhdl_libs: List of required VHDL libraries, names matching corresponding <NAME> entry in *git*: or *subversion*:

documentation:

Listing 22: example settings.yml entry for documentation

```
documentation:
  project_title: 'Project Documentation Title'
  project_version: '2019.1'
  project_author: 'Electronic System Design Group, Technology'
  project_org: 'Science and Technology Facilities Council'
  project_release:
    doxy_version: 1.8.14
    dot_version: 2.40.1
    sphinx_version: 1.8.2
    image_path: common/images
    logo_path: common/logo
    logo_name: logo.png
    source_path: common/source
```

(continues on next page)

(continued from previous page)

```
language: vhdl
restricted_src: False
doc_clean: True
release_uri: 'https://bitbucket.org/mjroberts/fpgaflow/branch/release'
issue_uri: False
releases_document_name: False
doxy_mainpage:
    name: 'README.md'
    autogen_pagenlinks: True
    autostruct:
        - 'readme_header.md'
        - 'readme_description.md'
```

project_title:

The Name of the Current Project Documentation.

project_version:

The Version Number of the Project Documentation in the form:

YYYY.NN

project_author:

The Project Documentation Author.

project_org:

The Project Documentation Organisation.

project_release:

The Project Documentation Release Tag.

doxy_version:

The Version of doxygen to use to build VHDL documentation.

Note: This version should be available on the host system and this value must be included in the *documentation: doxygen: support_tools:* within the configuration file (see *Configuration*).

dot_version:

The Version of graphviz used by doxygen when building documentation.

Note: This version should be available on the host system and this value must be included in the *documentation: dot: support_tools*: within the configuration file (see [Configuration](#)).

sphinx_version:

The Version of sphinx used when building documentation.

Note: This version should be available on the host system, either globally installed or included in the python virtual environment (see [Python Modules](#)) and this value must be included in the *documentation: sphinx: support_tools*: within the configuration file (see [Configuration](#)).

image_path:

The path of the image directory to include in the generated documentation. This path is relative to: ./docs

logo_path:

The path of the logo directory to include in the generated documentation. This path is relative to: ./docs

logo_name:

The name of the logo file, which must exist in the *logo_path*: to use in the generated documentation.

source_path:

The path additional source directory to include in the generated documentation. This path is relative to: ./docs

language:

The main language used in the project.

python Documentation will be generated using sphinx only.

vhdl Documentation will be generated using doxygen from VHDL source code. This will then be included and referenced by sphinx which provides the top-level documentation for the project.

Note: This language must be included in the *documentation: supported_languages*: within the configuration file (see [Configuration](#)).

`restricted_src:`

When this option is set True doxygen is prevented from including source code in the generated documentation.
Valid values are: True or False.

Note: `restricted_src:` defaults to True if the option is not included in the settings file.

`doc_clean:`

When this option is set True the documentation build paths are deleted prior to building the project documentation.
Valid values are: True or False.

`release_uri:`

Using `releases` to handle changelogs. See `releases_usage`. This is currently configured for bitbucket so /%s is appended to the end of the supplied URL automatically.

Note: `release_uri:` is optional, if not used it should be set to False in the settings file.

`issue_uri:`

Using `releases` to handle changelogs. See `releases_usage`.

Note: `issue_uri:` is optional, if not used it should be set to False in the settings file.

`releases_document_name:`

Using `releases` to handle changelogs. See `releases_usage`. If not defined here it will default to `changelog.rst`.

Note: `releases_document_name:` is optional, if not used it should be set to False in the settings file.

`doxy_mainpage:`

These options define the doxygen mainpage used to reference any pages generated by doxygen from source code, which is then referenced by the top-level documentation generated by sphinx.

name: Name of the mainpage to generate.

autosectuct: A list of files, which should be placed in the projects `docs/doxygen/source` directory, which should be added to the mainpage used by doxygen. The order of the list defines the order the contents of these files will be added to the mainpage.

autogen_pagelinks: Configures if the documentation generated by doxygen should be parsed to (re)generate links to pages to include on the mainpage. Valid values are: True or False.

This will automatically generate a file named: <lowercase_name>_links.md where <lowercase_name> matches the name of the mainpage to generate defined by name::

Note: When generating documentation doxygen uses either the @page uniquename or \page uniquename tags to define the name of the generated page. By using the convention of suffixing page to the uniquename so that it becomes: uniquenamepage it is possible for the docflow.py script to automatically add these pages as a list of links on mainpage generated by doxygen.

This option will cause doxygen to generate documentation twice, once to generate the pages, the second time to reference the pages on it's mainpage.

Electronic System Design Group

1.1.1.11 Utils

The following utilities are provided with FPGAFlow to aid the management of FPGAFlow on the users system.

By adding the following location to the user's path these can be accessible from anywhere on the system:

Listing 23: example entry in ~/.cshrc

```
setenv REPO_UTILS $REPO_ROOT/tools/fpgaflow/scripts/python/utils
set path = ($REPO_UTILS $path)
```

pipenv_installer.py

pipenv_installer.py provides a basic method to install the required *Python Modules* as well as *Additional Modules* from \$REPO_ROOT/tools without placing the addition tools in the resulting Pipfile.

Note: pipenv_installer.py will backup existing Pipfile and Pipfile.lock files.

Creating Virtual Environment

By running this command, pipenv_installer.py will remove any existing virtual environment and create a new fresh environment containing **only** the *Python Modules*. This will be represented by the resulting Pipfile.

Listing 24: pipenv_installer.py usage

```
# Installation:
pipenv_installer.py
```

Creating Virtual Environment with Additional Modules

By running this command, `pipenv_installer.py` will remove any existing virtual environment and create a new fresh environment containing the *Python Modules*. **and** the *Additional Modules*. The resulting Pipfile will only represent the *Python Modules* with **no** reference to the *Additional Modules*.

The most recent version of the additional module will be installed.

Listing 25: `pipenv_installer.py` additional module usage

```
# Installation with Additional Modules:  
pipenv_installer.py [<MODNAME>-<ORG> [<MODNAME>-<ORG>] ...]
```

Note: Additional Modules **must** be in the form>: <MODNAME>-<ORG>.

Updating Additional Modules

By running this command, `pipenv_installer.py` will uninstall the specified *Additional Modules* from the virtual environment and install the most recent version of the additional module.

The resulting Pipfile will only represent the *Python Modules* with **no** reference to the *Additional Modules*.

Listing 26: `pipenv_installer.py` additional module update usage

```
# Updating Additional Modules:  
pipenv_installer.py update [<MODNAME>-<ORG> [<MODNAME>-<ORG>] ...]
```

Note:

- Additional Modules **must** be in the form>: <MODNAME>-<ORG>.
 - Additional Modules can also be installed to an existing virtual environment using ths method.
-

Electronic System Design Group

1.1.1.12 Vendor IP

Description

`vendor_ip` provides a mechanism to manage *FPGA* specific IP components which are generated via tools provided as a part of the vendor design suite. The `vendor_ip` can then be included in project via the corresponding *Settings* file.

Configuration File

`vendor_ip_layout`:

Listing 27: example of config.yml entry for vendor_ip layout section

```
vendor_ip_layout:
  - vendor_ip:
    - <VENDOR>:
      - <TOOL_VERSION>:
        - common_wrapper_files:
          - <FAMILY>:
            - <IPCAT>:
              - <IPSUBCAT>:
                - <NAME>:
                  - constraints:
                  - docs:
                  - src:
                    - vhdl:
                    - vhdl_packages:
                    - xml:
    - <DEVICE>:
      - <IPCAT>:
        - <IPSUBCAT>:
          - <NAME>:
            - constraints:
            - docs:
            - src:
              - ip:
              - vhdl:
              - vhdl_packages:
              - xml:
```

<IPCAT>:

interfaces

Interfaces to externally connected devices.

debug

Components used for debug tasks.

clock_management

PLLs and DCMs.

memory

FIFOs.

<IPSUBCAT>:

Subcategories to logically group <IPCAT>.

interfaces

- phy
- jesd204b
- external_memory

<NAME>:

IP name.

Settings File

Listing 28: example of settings.yml entry for ip section

```
ip:  
  <IPCAT>:  
    <IPSUBCAT>:  
      <IP_NAME>:  
        enabled: <True|False>  
        library: <lib_name>  
        wrapper_file: <wrapper_name>_wrapper  
  <IPCAT>:  
    <IPSUBCAT>:  
      enabled: <True|False>  
      library: <lib_name>  
      wrapper_file: <wrapper_name>_wrapper
```

Common Wrapper Files

Common wrapper files allow wrapper files to be used across multiple devices within the same *FPGA* family. The . / src/vhdl directories in both <DEVICE> and common_wrapper_files locations are parsed for a corresponding .vhd source file matching the name defined by wrapper_file:. If the named file exists in *both* locations the one located in the <DEVICE> path will take precedence over the one located in the common_wrapper_files path.

The script will generate the search paths for wrapper files automatically, using both the <IP_NAME> and <wrapper_name> portion of the wrapper_file: name as the value for <NAME> in the constructed vendor_ip_layout structure.

Electronic System Design Group

1.1.1.13 VUnit Integration

FPGAFLOW uses VUnit to handle HDL libraries and dependencies for FPGA Vendor project generation and the simulation of HDL Modules. Configuration of VUnit is handled by the `vunit_args:` section of the `Settings` file.

Standard Libraries

Standard libraries are located in a precompiled area, so that they only require compiling once per version of Modelsim and FPGA tool version.

Currently the script compiles standard libraries for all families and libraries. However for each library to be added to the generated VUnit object it needs to be included in the corresponding list of simulation libraries under `xilinx:` or `altera:` in the `Configuration` file.

Standard libraries are generated in:

```
$SIM_PRE_COMPILED_LIBS_PATH/<VENDOR>/<TOOL_VERSION>/<SIM_VENDOR>_<SIM_VERSION>/  
→standard
```

Note: The values here are used by `Tag Substitution` replacing the <UPPERCASE> tags with corresponding values from the `Settings` file.

Project IP Libraries

Project specific IP libraries are generated in:

1.1.2 Indices and Tables:

- genindex
- modindex
- search

Python Module Index

a

arguments, 8

c

customlogging, 9

d

docflow, 10

e

environmentsetup, 20

f

fpgavendor_iface, 24

funcs, 27

p

pipenv_installer, 29

projectmanager, 29

s

setup, 34

v

version, 34

vunit_iface, 36

Index

A

about() (in module version), 35
add_environment_variable()
 (environmentsetup.ProjectEnvironment
 method), 21
add_hdl_files() (vunit_iface.VUnitProject method), 36
add_ip() (fpgavendor_iface.FpgaProject method), 24
add_standard_libraries()
 (vunit_iface.VUnitProject
 method), 37
add_vivado_sim_dependencies()
 (vu-
 nit_iface.VUnitProject method), 37
Arguments (class in arguments), 8
arguments (module), 8

B

backup_project()
 (fpgavendor_iface.FpgaProject
 method), 24

C

check_if_supported()
 (environmentsetup.ProjectEnvironment
 method), 21
checkout_enabled (arguments.Arguments attribute), 8
clean (arguments.Arguments attribute), 8
clean_path() (in module funcs), 27
compile_project_ip() (vunit_iface.VUnitProject method),
 37
compile_standard_libraries()
 (vunit_iface.VUnitProject
 method), 38
config (arguments.Arguments attribute), 8
config_logger() (in module customlogging), 9
configure_documentation_tool()
 (environmentsetup.ProjectEnvironment
 method), 21
configure_fpga_vendor_tool()
 (environmentsetup.ProjectEnvironment
 method), 22
configure_gui() (vunit_iface.VUnitProject method), 38

configure_license()
 (environmentsetup.ProjectEnvironment
 method), 22

configure_mode()
 (environmentsetup.ProjectEnvironment
 method), 22

configure_molesim_environment()
 (environmentsetup.ProjectEnvironment
 method), 22

configure_paths() (environmentsetup.ProjectEnvironment
 method), 22

Const (class in funcs), 27

Const.ConstError, 27

constant() (in module customlogging), 9

construct_local_path()
 (projectmanager.RepoFlow
 method), 32

construct_remote_path()
 (projectmanager.RepoFlow
 method), 33

copy_files_from_dir() (in module funcs), 28

create_quartus_project()
 (fpgavendor_iface.FpgaProject
 method), 24

create_vivado_project()
 (fpgavendor_iface.FpgaProject
 method), 25

CRITICAL (customlogging.LogLevelsConsts attribute),
 9

customlogging (module), 9

D

DEBUG (customlogging.LogLevelsConsts attribute), 9
dev_flag (arguments.Arguments attribute), 8

docflow (module), 10

E

environmentsetup (module), 20

ERROR (customlogging.LogLevelsConsts attribute), 9

errorexit() (in module customlogging), 9

F

FpgaProject (class in fpgavendor_iface), 24

fpgavendor_iface (module), 24
 funcs (module), 27

G

generate_automodule() (docflow.ProjectDoc method), 11
 generate_doxyfile() (docflow.ProjectDoc method), 11
 generate_doxygenmainpage() (docflow.ProjectDoc method), 12
 generate_include() (docflow.ProjectDoc method), 12
 generate_index_heading() (docflow.ProjectDoc method), 13
 generate_indices_and_tables() (docflow.ProjectDoc method), 13
 generate_sphinx_index_file() (docflow.ProjectDoc method), 13
 generate_sphinx_modules() (docflow.ProjectDoc method), 14
 generate_timestamp() (in module fpgavendor_iface), 25
 generate_tocree() (docflow.ProjectDoc method), 14
 get_category_from_path() (projectmanager.RepoFlow method), 33
 get_contrib_lib_from_path() (projectmanager.RepoFlow method), 33
 get_envvar() (environmentsetup.ProjectEnvironment method), 22
 get_kwarg() (in module funcs), 28
 get_lib_from_name() (projectmanager.ProjectDependency method), 30
 get_project_file() (fpgavendor_iface.FpgaProject method), 25
 get_version() (version.Version method), 35

I

INFO (customlogging.LogLevelsConsts attribute), 9
 is_verilog_header() (vunit_iface.VUnitProject static method), 38

L

layout_tag_attr_replace() (projectmanager.ProjectDependency method), 30
 layout_to_dir() (projectmanager.ProjectDependency method), 31
 load_settings_from_yaml() (docflow.ProjectDoc method), 15
 LogLevelsConsts (class in customlogging), 9

M

mand_missing() (in module customlogging), 9

O

open_gui (arguments.Arguments attribute), 8

P

path_missing() (in module customlogging), 10

pipenv_installer (module), 29
 preprocess_sphinxconf() (docflow.ProjectDoc method), 15
 process_repository_config() (projectmanager.RepoFlow method), 34
 process_sphinx_conf_file() (docflow.ProjectDoc method), 17
 process_sphinx_makefile() (docflow.ProjectDoc method), 18
 ProjectDependency (class in projectmanager), 29
 ProjectDoc (class in docflow), 10
 ProjectEnvironment (class in environmentsetup), 21
 projectmanager (module), 29
 prune_path() (projectmanager.ProjectDependency method), 31
 prune_path_list() (projectmanager.ProjectDependency method), 31

R

read_compile_order() (vunit_iface.VUnitProject method), 38
 readfile_as_list() (in module funcs), 28
 replace_tag_with_attr_value() (in module funcs), 28
 RepoFlow (class in projectmanager), 32
 resolve_gui_init_script() (vunit_iface.VUnitProject method), 39
 resolve_tool_version() (in module fpgavendor_iface), 25
 resolved_master_tags() (projectmanager.VendorIpDependency method), 34
 retag_path() (projectmanager.ProjectDependency method), 32
 run_doxxygen() (docflow.ProjectDoc method), 18
 run_ip_generate() (in module fpgavendor_iface), 26
 run_ip_setup_simulation() (in module fpgavendor_iface), 26
 run_quartus_sh() (in module fpgavendor_iface), 26
 run_sphinx() (docflow.ProjectDoc method), 18
 run_vivado() (in module fpgavendor_iface), 27

S

sect_break() (in module customlogging), 10
 set_args_from_dict() (environmentsetup.ProjectEnvironment method), 22
 set_attr_from_path() (environmentsetup.ProjectEnvironment method), 23
 set_doxy_paths() (docflow.ProjectDoc method), 18
 set_envattr() (environmentsetup.ProjectEnvironment method), 23
 set_image_path() (docflow.ProjectDoc method), 19
 set_kwargs() (in module funcs), 28
 set_logo() (docflow.ProjectDoc method), 19

set_path_environ()
 (environmentsetup.ProjectEnvironment
 method),
 23

set_source_path() (docflow.ProjectDoc method), 19

set_sphinx_paths() (docflow.ProjectDoc method), 20

set_top_refs() (projectmanager.ProjectDependency static
 method), 32

set_version() (version.Version method), 35

setattr_from_envvar()
 (environmentsetup.ProjectEnvironment
 method),
 24

settings (arguments.Arguments attribute), 8

setup (module), 34

setup_logging() (in module customlogging), 10

setup_simulation_options() (vunit_iface.VUnitProject
 method), 39

source_code_publication_msg() (docflow.ProjectDoc
 method), 20

strip_tag() (in module funcs), 29

T

tb_cfg_encode() (in module vunit_iface), 39

top_dir_lookup() (projectmanager.ProjectDependency
 static method), 32

V

validate_file() (in module funcs), 29

VendorIpDependency (class in projectmanager), 34

Version (class in version), 35

version (module), 34

vu (vunit_iface.VUnitProject attribute), 36

vunit_iface (module), 36

VUnitProject (class in vunit_iface), 36

W

WARNING (customlogging.LogLevelsConsts attribute),
 9

writefile_as_list() (in module funcs), 29